



NOTES:

1. Each **AquaCell** side panel (part #2476600003) has two standard 6 inch inlets with integrated pipe stopper.
 - a) The two sprues of the pipe stopper can be cut/broken to activate this pipe stopper.
 - b) Ensure the 6 inch pipe will seat into the open inlet. PVC SDR-26/35 (ASTM D3034) can be used. For other pipe type connections, use flexible coupler (provided by others).
2. With the tank wrapped in geotextile, locate the 6 inch sidewall inlet opening. Using a small blade cutter, cut an X in the center of the fabric over the open sidewall port.
3. Using a separate piece of geotextile, cut an X in the fabric slightly larger than the pipe and push the spigot end through it. Pull the fabric flaps around the pipe.
4. Push the spigot end of the PVC pipe through the cut hole on the tank geotextile, and slide the geotextile around the pipe up against the side wall of the tank. Seal the fabric flaps around the pipe with a stainless steel band. Seal the pipe geotextile to the tank geotextile using Duct Tape or other adhesive (steel band and adhesive provided by others).



Managing water better since 1955.
950 Winter Street
Waltham, MA 02451
wavin.us.com
wavintechsupport@orbia.com

Title: Six-inch PVC Pipe to AquaCell Side Panel Detail

The design details/specifications presented in this document are for informational & reference purposes only and are subject to change without notice. Responsibility for design of any AquaCell system rests solely with the original design engineer of record. For questions, contact: wavintechsupport@orbia.com.	Drawn by: HJD	Approved by: KS	Sheet <u>1</u> of <u>1</u>
	Scale: NTS	Revision: 0	
	AQ-100-22	Date: 8/3/2024	