DAT\_IN CLK\_IN R2 R1 To avoid damaging tracks, do not snap off. Use hacksaw to separate boards if required. \_\_\_\_c1 \_\_\_\_c2 C4 сз DAT\_IN CLK\_IN GND с5 сь 83 C7 wyolum.com github.com/wyolum/ClockIOT C9 C10 C12 C11 C13 C14 C16 C15 https://github.com/wyolum/ClockIOT www.wyolum.com Sheet: File: ClockIOT.kicad\_pcb Title: ClockIOT