EQUINE PERFORMANCE LABS

Stirling Ultracold Freezer

Quick Maintenance and Operation Guide

Turning Freezer On and OFF

ON – Press and hold On/Off button for **two beeps.**

OFF – press and hold On/Off Button for **three beeps**

Changing Temperature Set Point

Hold **Set Temp** button until **LED lights** (2-3 seconds).

Use **Up/Down Arrows** (D): Brief Press = ±1°C; hold 5 seconds = ±10°C.

Release **Set Temp Button**

To view current temp set point – press the **Set Temp Button** briefly

Maintenance Monthly: Stirling Ultracold Freezer

Defrost Freezer Weekly / as needed
Open the top lid while keeping the foam lid in place. Let the ice on the lid melt naturally and wipe away the excess water.

Vacuum Filter – Monthly / as needed
Slide filter out and vacuum

Note: Frequency may increase if the environment is dusty.

IMPORTANT: Please **DO NOT** place dry ice in freezer.

SCAN OR CLICK

Need more details?

Scan here to access the full Stirling freezer setup and operating manual.

SCAN OR CLICK

Ready to restock?

Scan here to start a new order with Equine Performance Labs

OUR OFFICE
5540 N. Lamar Blvd, Building B
Austin, TX 78756

FOR MORE ASSISTANCE
stirling.com email