3412.6 Evaluation process. The evaluation process specified herein shall be followed in its entirety to evaluate existing buildings. Table 3412.7 shall be utilized for tabulating the results of the evaluation. References to other sections of this code indicate that compliance with those sections is required in order to gain credit in the evaluation herein outlined. In applying this section to a building with mixed occupancies, where the separation between the mixed occupancies does not qualify for any category indicated in Section 3412.6.16, the score for each occupancy shall be determined and the lower score determined for each section of the evaluation process shall apply to the entire building.

Where the separation between mixed occupancies qualifies for any category indicated in Section 3412.6.16, the score for each occupancy shall apply to each portion of the building based on the occupancy of the space.

3412.6.1 Building height. The value for building height shall be the lesser value determined by the formula in Section 3412.6.1.1. Chapter 5 shall be used to determine the allowable height of the building, including allowable increases due to automatic sprinklers as provided for in Section 504.2. Subtract the actual *building height* in feet (mm) from the allowable height and divide by $12^{1}/_{2}$ feet (3810 mm). Enter the height value and its sign (positive or negative) in Table 3412.7 under Safety Parameter 3412.6.1, Building Height, for fire safety, means of egress and general safety. The maximum score for a building shall be 10.

3412.6.1.1 Height formula. The following formulas shall be used in computing the building height value.

Height value, feet =
$$\frac{(AH) - (EBH)}{12.5} \times CF$$
 (Equation 34-1)

Height value, stories = $(AS - EBS) \times CF$ (Equation 34-2)

where:

AH = Allowable height in feet (mm) from Table 503.

EBH = Existing *building height* in feet (mm).

AS = Allowable height in stories from Table 503.

EBS = Existing building height in stories.

CF = 1 if (AH) - (EBH) is positive.

CF = Construction-type factor shown in Table 3412.6.6(2) if (AH) - (EBH) is negative.

Note: Where mixed occupancies are separated and individually evaluated as indicated in Section 3412.6, the values *AH*, *AS*, *EBH* and *EBS* shall be based on the height of the occupancy being evaluated.