pursuant to the Law.

Distributing Pipe means any pipe not owned by the Water Distribution

Company (other than a warning, overflow or flushing pipe) conveying water from a Ground Storage Tank, storage cistern, or from hot water apparatus supplied

from a cistern and under pressure from that cistern.

Distribution System means the system consisting (wholly or mainly) of water

pipes owned or operated by a licensee and used for the distribution of Wholesome Water to the Point of Delivery to Premises or Customers and includes any plant and equipment, including metering equipment, owned or operated by the licensee in connection with the

distribution of water.

Entry Point means the physical connection point at which the water

enters the Customer Water Fittings.

Fire Service means the pipes, tanks, pumps and fittings installed for

the purpose of firefighting.

Ground Storage Tank means the receiving tank after the Point of Delivery to the

Customer from the Distribution System for storing water for subsequent use, and which does not include a cistern.

Improvement Notice means a notice prepared by the Distribution Company

and approved by the Bureau for the purpose of instructing the Responsible Person to comply with the

Regulations.

Law means Law No (2) of 1998 Concerning the Regulation of

the Water and Electricity Sector in the Emirate of Abu Dhabi, Law No (17) of 2005 and Law No (12) of 2008 concerning the Regulation of the Wastewater Sector, as

amended.

Licence means a licence issued by the Bureau pursuant to the

Law.

Low-rise Building means a building up to 10 metres height (G+1).

Overflow Pipe means a pipe from a tank/cistern in which water flows

only when the water level in the tank/cistern exceeds a

Guide to Water S	Supply Regulations 2017			
Author	Document	Version	Issue date	Approved by
KR/MSH	ER/P04/100	Issue 3	15 Dec. 2016	SSQ
		Page 6 of 8	6	