17.4.3 Localised lighting

In many exterior workplaces, the places where detailed visual work is carried out are limited. In this situation, there is little point in lighting the whole site to the level necessary for the detailed work. A better approach is to light the whole site to the level necessary for safe movement and to use localised lighting for the work areas. This localised lighting may be permanent, for a fixed working area, or temporary, for a construction site. The latter lighting may be powered from a generator.