Line of sight is 600mm above C inside lane at point of obstruction.


S = SIGHT DISTANCE IN METERS

R = RADIUS OF THE Q OF THE LANE NEAREST THE OBSTRUCTION IN METERS.

m = DISTANCE FROM @ OF THE LANE NEAREST THE OBSTRUCTION IN METERS.

V = DESIGN SPEED FOR "S" IN kph.

| DESIGN SPEED | SIGHT DISTANCE |
|--------------|----------------|
| kph | kph |
| 30 | 30 |
| 40 | 45 |
| 50 | 65 |
| 60 | 85 |
| 70 | 105 |
| 80 | /30 |
| 90 | 160 |
| 100 | 190 |
| 110 | 220 |
| 120 | 255 |
| 130 | 290 |



Formula applies only when "S" is less than or equal to the curve length.

For sustained downgrades, see Section 204.05.

Figure 200.03

Stopping Sight Distance on Horizontal Curves

If the vehicle is not skidding, all forces are in equilibrium and are governed by the following equation:

Centrifugal Factor =
$$e + f = \frac{0.0079 \text{ V}^2}{\text{R}} = \frac{\text{V}^2}{127 \text{ R}}$$

Where:

 $\begin{array}{lll} e & = & Superelevation\ rate\ in\ m\ per\ m \\ e_{max} & = & Maximum\ superelevation\ rate\ for \\ a\ given\ condition \\ f & = & Side\ friction\ factor \\ R & = & Curve\ radius\ in\ m \\ V & = & Velocity\ in\ kph \end{array}$

This equation is used to design superelevated curves for comfortable operation. Standard superelevation rates are designed to keep the portion of centrifugal force countered by tire friction within allowable limits.

202.02 SUPERELEVATION STANDARDS

Maximum superelevation rates for various roadway classifications are shown on Table 200.03. Table 200.04 shows values for design

elements related to speed and horizontal curvature.

| Table 200.03 Maximum Superelevation Rates | |
|--|--------------|
| Roadway Classification | e_{max} |
| Freeways | 0.06 |
| Expressways | 0.06 |
| Ramps | 0.06 |
| Main Roads and Collectors | 0.04 |
| Sector Roads | Normal Crown |

202.03 CITY ROAD CONDITIONS

Lower superelevation rates may be necessary in urban areas where restricted speed zones or intersections are controlling factors. In addition, existing road grades, curbs, or drainage may prove difficult to alter. Such conditions may warrant, for example, a reduction in the superelevation rate, different rates for each half of the roadbed, or both. In warping road areas for drainage, adverse superelevation should be avoided.