## 6.6.2. Methods of Flow Measurement

Summary of permitted methods of flow measurement is shown in Table 6-9. Consultant is responsible for correct application of the method to the site conditions.

Instrument type	Open Channel	Closed Conduit (gravity/non-full bore)	Closed Conduit (pressurized)	Field Indication	Remote Indication	Point Level	Continuous Measurement
Ultrasonic					·		•
Doppler Effect (continuous/ pulse)	✓	1	~ /	<b>√</b>	1		✓
Ultrasonic Transit Effect	✓		<b>V</b>	<b>*</b>	<b>V</b>		✓
Electromagnetic	<b>V</b>	<b>V</b>	<b>*</b>		<b>✓</b>		✓
Cross Correlation	~	1	<b>✓</b>	<b>V</b>			✓
Paddle Switch			<b>V</b>	✓	✓	✓	
Radar Doppler Effect	<b>✓</b>	✓		✓	✓		✓
Weir	✓			✓	✓		✓
Flume	✓			✓	✓		✓

Table 6-9 - Methods of Flow Measurement