- C. The contractor agrees that he/she shall assume sole and complete responsibility for his/her work, including safety of all persons and property; and that the contractor shall defend, indemnify, and hold DMAT harmless from any and all liability, real or alleged, in connection with the contractor's performance of work on this project, excepting for liability arising from the sole negligence of DMAT or its employees.
- D. Any requirement of this specification which conflicts with or is in violation of any government rule, ordinance, regulation, etc. shall be void. The contractor shall notify the Engineer immediately of any such requirement found in this specification.
- E. The contractor shall, throughout the course of this work, comply with all rules, ordinances, regulations, etc. set forth by agencies having jurisdiction, which apply to the work site, the contractor, and/or his/her employees.

26.2 Part 2 Installation

26.2.1 SCOPE

A. This section covers the civil works installation of new piped stormwater systems, including pumping mains and their connection to the existing network.

26.2.2 Submittals

In addition to the requirements of Section 01300, before commencing any new installation or modifications to the existing network, the Contractor shall confirm the layout and details of the existing stormwater system, electrical control and monitoring network, mechanical and electrical equipment and ancillary apparatus and shall submit them for the Engineer's approval.

Following the Engineer's approval the Contractor shall then submit the detailed proposals for the new network and the details of connections to the existing network, including new discharge points, eg to watercourses, for the approval of the Engineer.

26.2.3 Delivery, Storage, and Handling

A. `Delivery, storage and handling of products and materials shall be in accordance with Section 01600, the manufacturer's recommendations and the following provisions: