Figure 6.4:	Example of utility corridors arrangements at a
	Street/Avenue roundabout5
Figure 6.5:	Example of a grade separated junction,
	Sultan Bin Zayed the First Street, Abu Dhabi 6
Figure 6.6:	Example of transitioning of utility corridors at
	a T-junction 6
Figure 6.7:	Example of transitioning of utility corridors at a
	junction leg or longitudinal Street expansion 7
Figure 6.8:	Typical utility arrangement within a utility tunnel 8
Figure 6.9:	Example of wet utilities in a utility tunnel9
Figure 6.10:	Example of dry utilities in a utility tunnel 9
Figure 6.11:	Typical examples of utilities at bridges10
Figure 6.12:	Example of pedestrian underpass in a
	City Bouvelard11
Figure 6.13:	Example of a dedicated transit corridor for an
	LRT in a Town Avenue12