

FIGURE 3.1 Ventilation system.

environmental tobacco smoke (ETS): the "aged" and diluted combination of both side-stream smoke (smoke from the lit end of a cigarette or other tobacco product) and exhaled mainstream smoke (smoke that is exhaled by a smoker). ETS is commonly referred to as secondhand smoke. This definition includes smoke produced from the combustion of cannabis and controlled substances and the emissions produced by electronic smoking devices.

equipment well: an area (typically on the roof) enclosed on three or four sides by walls that are less than 75% free area, and the lesser of the length and width of the enclosure is less than three times the average height of the walls. The free area of the wall is the ratio of area of the openings through the wall, such as openings between louver blades and undercuts, divided by the gross area (length times height) of the wall.

ETS-free area: an area where no smoking occurs that is separated from ETS areas according to the requirements of this standard.

Informative Note: A no-smoking area is not necessarily an ETS-free area.

ETS area: spaces where smoking is permitted, as well as those not separated from spaces where smoking is permitted in accord with the requirements of Section 5 in this standard.

exfiltration: uncontrolled outward air leakage from conditioned spaces through unintentional openings in ceilings, floors, and walls to unconditioned spaces or the outdoors caused by pressure differences across these openings due to wind, inside-outside temperature differences (stack effect), and imbalances between outdoor and exhaust airflow rates.

industrial space: an indoor environment where the primary activity is production or manufacturing processes.

infiltration: uncontrolled inward air leakage to conditioned spaces through unintentional openings in ceilings, floors, and

walls from unconditioned spaces or the outdoors caused by the same pressure differences that induce exfiltration.

mechanical ventilation: ventilation provided by mechanically powered equipment such as motor-driven fans and blowers but not by devices such as wind-driven turbine ventilators and mechanically operated windows.

microorganism: a microscopic organism, especially a bacterium, fungus, or protozoan.

natural ventilation: ventilation provided by thermal, wind, or diffusion effects through doors, windows, or other intentional openings in the building.

net occupiable area: the floor area of an occupiable space defined by the inside surfaces of its walls but excluding shafts, column enclosures, and other permanently enclosed, inaccessible, and unoccupiable areas. Obstructions in the space, such as furnishings, display or storage racks, and other obstructions, whether temporary or permanent, are considered to be part of the net occupiable area.

nontransient: occupancy of a dwelling unit or sleeping unit for more than 30 days.

occupant sensor: a device such as a motion detector or a captive key system that detects the presence of one or more persons within a space.

occupiable space: an enclosed space intended for human activities, excluding those spaces that are intended primarily for other purposes, such as storage rooms and equipment rooms, and that are only occupied occasionally and for short periods of time.

occupied mode: when a zone is scheduled to be occupied.

occupied-standby mode: when a zone is scheduled to be occupied and an occupant sensor indicates zero population within the zone.