maintained at the proper temperature 24 hours a day.

- 5. The Contractor shall visually inspect all products upon delivery and report any damage to the Engineer.
 - Any products damaged during delivery, storage or installation shall be marked by the Contractor and set aside.
 - b. Proposals for repair of any damaged products shall be submitted in writing to the Engineer for approval.
 - No repairs to damaged products shall be attempted without the Engineer's approval.
 - d. Any damaged products deemed unsuitable for repair by the Engineer shall be removed from site and replaced at the Contractors expense.

8.1.9 Pre-Installation Co-Ordination

A. Pre-Installation Conference

- 1. Prior to the start of GRC installation, meet at the site and review the installation procedures and co-ordination with other work.
- Meetings shall include Contractor, Engineer and Major material manufacturers as well as others whose work must be co-ordinated with the GRC work.

B. Co-ordination with Inserts

 Ensure co-ordination between GRC work and concrete work such that all inserts and fasteners required for the proper installation of GRC work are correctly pre-installed.

C. Pre-Installation Inspection

- 1. Examine all parts of the supporting structure and the conditions under which the GRC work is to be installed.
- 2. Notify the Engineer in writing of any conditions detrimental to the proper and timely completion of the work.
- 3. Do not proceed with the installation of GRC work until unsatisfactory conditions have been corrected in a manner acceptable to the Engineer.
- D. The Work of this Section shall be completely co-ordinated with the work of other sections.