I U S T T H E F A C T S >>>

TPMS Sensor ID Number Locator

The TPMS Sensor ID can be located in various locations on the TPMS sensor and can be either numeric or alphanumeric. TPMS sensors using a numeric ID will consist of 0-9. TPMS sensors using a alphanumeric ID will consist of 0-9 and A-F. These 16 characters provide more than 2 trillion sensor ID combinations. So, a TPMS sensor ID will normally be 7-8 characters, but can be 10. The following are examples of sensor ID locations and are not all inclusive of every sensor.

IMPORTANT: After removing the sensor from the tire, use our TPMS Application and Illustrated Parts Guide STTPMS-13 to determine the appropriate sensor needed to replace the OE sensor. Determine the OE sensor identification number by reading the sensor or using a scan tool.



Typical OE Sensor ID Number Location



Schrader® Style Sensor

Chevy, Chrysler, Dodge, Ford, Infiniti, Isuzu, Jeep, Mitsubishi, Nissan, Saab, Saturn, Subaru, Suzuki



Schrader® Style Sensor

Buick, Cadillac, Chevy, GMC, Hummer, Isuzu, Pontiac, Saturn



Pacific Style Sensor

Acura, Honda, Infiniti, Lexus, Nissan, Pontiac, Scion, Toyota



Siemens/Continental Style Sensor

Audi, Chrysler, Dodge, Hyundai, Jaguar, Jeep, Mitsubishi, Volkswagen



Banded Sensor

Ford, Lincoln, Mercury, Mazda



Continental Style Sensor

Chrysler, Honda, Hyundai, Jaguar, Kia, Land Rover, Mazda, Suzuki, Volvo, Volkswagen



Snap-In Style Sensor

Buick, Cadillac, Chevy, Dodge, GMC, Ford, Jeep, Mercury, Mitsubishi, Pontiac, Saab, Subaru, Suzuki, Volvo



Adjustable Angle Sensor

Mercedes-Benz













