


3.6 Estructura general de los reductores de tornillo sin fin S..37 – S..97, S..37p – S..97p



18014398528786187

[1] Piñón	[20] Válvula de salida de gases	[88] Circlip	[518] Arandela de ajuste
[2] Rueda	[22] Carcasa del reductor	[89] Capuchón	[519] Arandela de ajuste
[5] Tornillo sin fin	[25] Rodamiento	[100] Cubierta de inspección	[520] Arandela de ajuste
[6] Rueda helicoidal	[30] Rodamiento	[101] Tornillo de cabeza hexagonal	[521] Arandela de ajuste
[7] Eje de salida	[31] Chaveta	[102] Junta	[522] Arandela de ajuste
[9] Retén	[37] Rodamiento	[131] Capuchón	[523] Arandela de ajuste
[11] Rodamiento	[39] Circlip	[137] Arandela de apoyo	
[12] Circlip	[59] Tornillo de cierre	[506] Arandela de ajuste	
[19] Chaveta	[61] Circlip	[507] Arandela de ajuste	