








电池电压升5v





5V转3.3V




12V转5V



外部串口控制和电源输入 电池接口







串口数据给上层板
向上层板供电




电池电压检测

Title		
Size	Number	Revision
A4		
Date:	5-16-2026	Sheet of
File:	C:\Users\...\power.SchDoc	Drawn By:



Title		
Size	Number	Revision
A4		
Date:	5-16-2026	Sheet of
File:	C:\Users\...\power2.SchDoc	Drawn By:



Board Stack Report