```
// Experiment 3: Reading a Potentiometer using ESP32
// Define the analog pin
const int potPin = 12;
// GPIO12 is input only
void setup() {
  Serial.begin(115200);
  // Start Serial Monitor at 115200 baud rate
}
void loop() {
  int potValue = analogRead(potPin);
  // Read analog value (0-4095)
  Serial.print("Potentiometer Value: ");
  Serial.println(potValue);
  // Print the value
  delay(200);
  // Delay for readability
```