
Problem 16



This project uses Timer 1 in mode 1 (16-bit timer) with interrupt triggered every $\approx 50ms$. This 50ms is the basic unit of time that is used to make LED blink with T_ON = multiple of 50ms, and T_OFF = another multiple of 50ms.

For example if we set $T_ON = 10$, and $T_OFF = 20 \rightarrow$ the actual ON TIME = 10*50ms = 500ms, and OFF TIME = 20*50ms = 1000ms

This is done by using two counter variables, one for the ON_TIME and the other for the OFF_TIME.

Definitions

```
19 LED1_ON_TIME EQU 10
20 LED1_OFF_TIME EQU 20
21 LED2_ON_TIME EQU 50
22 LED2_OFF_TIME EQU 30
23
24 COUNT_ON1 EQU 30H
25 COUNT_OFF1 EQU 31H
26 COUNT_ON2 EQU 32H
27 COUNT_OFF2 EQU 33H
28
29 LED1 EQU P3.7
30 LED2 EQU P3.6
31
32 LED1_STATE EQU 00H
33 LED2_STATE EQU 01H
```

19 to 22, defines the ON/OFF values for two LED (multiple of 50ms)
We need to define a counter for each TIME_ON and TIME_OFF (lines 24-27)
(29-30) Port pins connected to LEDs

We keep the status of the LEDs in two boolean variables as in lines 32,33

Main loop

```
42
            0000h
       org
43
       jmp
            Start
44 ORG 001BH
45 LJMP ISR_T1
47 ; CODE SEGMENT
48 :-----
49
      org 0100h
50
51 Start:
52
   MOV TMOD,#10H
    MOV TL1,#0B0H
54
55
    MOV TH1,#03CH
    SETB EA
56
    SETB ET1
57
    SETB TR1
58
    CLR LED1
59
    CLR LED2
61
     MOV COUNT_ON1, #LED1_ON_TIME
62
     MOV COUNT_OFF1,#LED1_OFF_TIME
63
     MOV COUNT ON2, #LED2 ON TIME
64
     MOV COUNT_OFF2, #LED2_OFF_TIME
65
66
67 START2:
68 JMP START2
```

First we jump to start label (43), where the interrupt vector of Timer1 overflow will be at address 001Bh.

When Timer1 overflow, the 8051 will be interrupted and execute the code at address 001Bh. So we put a jump to the starting code for our timer handler (45)

At 53, we set Timer 1 in mode 1

At 54-55, we initialize the Timer by 3CB0h, which will cause an overflow after counting 50000 clock cycle, and since the clock of the counter = $12M/12 = 1us \rightarrow$ the time passed will be 50ms

56-57, we enable Timer1 overflow interrupt (note that we must set both EA, and ET1)

ET1 → enable timer 1 overflow interrupt

EA → must be 1 to enable 8051 interrupt

58 → we make Timer1 run by setting TR1

Lines 62-65 initialize the ON/OFF counter for both LEDs

the main loop in our example do nothing! (as all the processing will be done by Timer1 overflow interrupt)

Timer1 Overflow Interrupt

```
71 ISR_T1:
72
      MOV TL1,#0B0H
      MOV TH1,#03CH
73
74 TEST LED1:
      JB LED1_STATE, LED1_ON
75
      CLR LED1
76
      DJNZ COUNT_OFF1, TEST_LED2
77
      SETB LED1 STATE
78
      MOV COUNT_OFF1, #LED1_OFF_TIME
79
80
      JMP TEST LED2
81 LED1 ON:
      SETB LED1
82
      DJNZ COUNT ON1, TEST LED2
83
      CLR LED1 STATE
      MOV COUNT ON1, #LED1 ON TIME
86 TEST_LED2:
```

First we re-initialize timer 1 by $2^16-50000 = 3CB0$ (72, 73) to enable it to count for a time of 50ms again

75→ test if the current state of LED1 is ON; if not, so it is OFF, and we will make

LED1 OFF (76). Then we decrement the OFF counter for LED1 (77) and if it becomes '0', we will change the state of the LED1 to ON (78), and re-initialize the off counter (79)

If LED1 state is ON (81), we make LED ON (82), then decrement the ON-counter (83)-if this counter becomes '0', we will change the state of LED1 to OFF (84), and re-initialize the ON-counter (85)

The same will be done for LED2 as shown below

```
86 TEST_LED2:
      JB LED2_STATE, LED2_ON
87
88
      CLR LED2
      DJNZ COUNT_OFF2, TEST_LED3
89
      SETB LED2_STATE
90
      MOV COUNT_OFF2, #LED2_OFF_TIME
91
    JMP TEST_LED3
92
93 LED2_ON:
94 SETB LED2
       DJNZ COUNT_ON2, TEST_LED3
95
       CLR LED2_STATE
      MOV COUNT_ON2, #LED2_ON_TIME
97
98 TEST_LED3:
99
100 RETI
```