
RaPi		Pwr
		1 (NC)
5	->	2 (SCL)
3	->	3 (SDA)
6	->	4 (GND)
8	->	5 (RX)
10	->	6 (TX)





www.raspberrypi-spy.co.uk