

VICTORIA + ALBERT

Barcelona 2 Freestanding Bathtub

Installation Guide

1 Inspect before you install

- Unpack the tub and check the surface and packaging for damage. Do not install a damaged product. Report freight damage within 24 hours.

2 Check the floor

- A filled cast stone tub can exceed 1,000 lb. Confirm the floor structure can support the load.

3 Position the drain

- Rough in a floor drain at the centre drain location shown on the specification sheet, allowing access for connection.

4 Plan the filler

- Install a floor-mount or wall-mount tub filler before setting the tub. Confirm spout reach and height.

5 Set and level

- Connect the waste and overflow, set the tub in position and level it. Seal the base with a sanitary silicone.

6 Test

- Fill the tub and check all connections for leaks before finishing the surrounding floor.

Installation must be carried out by a licensed, qualified professional

in accordance with local codes. Improper installation may void the warranty.