

## STM32 Cube IDE Installation Process

## Website:


1. For downloading the STM32 Cube IDE first visit the following website:

https://www.st.com/en/development-tools/stm32cubeide.html

2. Next Click on Get Software



3. Next Select the Operating System and the version of the IDE you want to download.



4. Click on **Accept** on the license agreement.



5. It will direct you to a page where you need to fill your **Name** and **Mail address**. Next click on **Download** to download the Stm32 Cube IDE. If you are Already registered on the**st.com** website, click on**Login/Register**.



## **Get Software**

If you have an account on my.st.com, login and download the software without any further validation steps.

Login/Register

## New user?


myST brings you a set of personalized features:

- Participate to ST Events
- Stay informed with ST eNewsletters
- o Get help with ST Online Support
- Discuss on the ST Community
- Benefit from our Online Design Tools
- Download Software
- Order free samples
- Manage your weekly product updates
- Buy ST Products & Tools

**Create Account** 

- 6. Once you create an account, a validation email will be sent on your registered mail id. Click on **Validate**, it will redirect you to the page on **Step 2**. Your download should start automatically now.
- 7. Extract the downloaded .zip file and double click on the application file .exe to start the installation process and follow the installation process till the end.






8. In the **Select components to install** section select both **SEGGER J-Link drivers** and **ST-LINK drivers**.



9. At the end of the installation process Cube IDE ask you to choose a workspace where your projects will be saved. Select the path of the workspace provided by Cube IDE itself or you can choose according to your need. Your installation process is now completed.



**Note:** All important steps and parts are highlighted with a red colour box for the proper understanding of the user. This document is for the use of education purpose only.