




## 2 Undefined Subscriber




## 3 Unauthorized subscriber




4 Telecommunication service not Supported




5 Call barred







8 Out of service area




10 SM sending Failure












15 MS error




16 The MS Supports No SMs





17 Full MS Memory




18 Congested SMApp









21 Unknown SMApp




22 Illegal Equipment







24 MS Switched Off




34 Unexpected Data from the HLR




35 Unexpected Data from the MSC




40 No Response to Route Query Request Returned from HLR




41 No MS Status Notification Response Returned from HLR




48 No Response from MSC




51 Rejected by MSC




52 Rejected by HLR




53 Rejected by the Signaling Gateway




56 HLR System Error




57 MSC System Error




61 MAPProxy Rejects MT Deliver Request




62 MTI Server Failed to Deliver an SM Due to Traffic Control




65 The Signaling Gateway Has Not Responded Within the Timeout Interval




66 Temporary ESME Interface Error




67 Invalid Interface




75 STP Failed to Transmit SMs




100 SMS Not Supported




155 Dual-Mode Subscriber of CDMA Network Roamed to GSM Network




156 MDN and MIN Not Contained in MT SM




214 SS7 Subsystem Failure



216 SS7 Network Failure/MTP Failure



218 SS7 Unqualified



254 Delivery Failed

