

c: W[TTD(x)]q=(oa:PA(x))
Init

rf

iico_data

Thread 0

a: R[TTD(x)]NExpq=(oa:PA(x))
proc:P0 poi:0
LDR X1,[X2]

iico_data

e: R0:X2q=x
proc:P0 poi:0
LDR X1,[X2]

f: Branching(pred)(valid:1 && af:1)
proc:P0 poi:0
LDR X1,[X2]

g: W0:X1q=42
proc:P0 poi:0
LDR X1,[X2]

d: W[PA(x)]q=42
Init

iico_data

iico_ctrl

iico_data

rf

b: R[PA(x)]q=42
proc:P0 poi:0
LDR X1,[X2]