

Make your taps land.

If your finger jiggles, the phone can read a tap as a swipe — and you land somewhere you didn't mean to. One setting fixes it: your tap counts where your finger first touches.

SET UP • ONE TIME **Switch on Tap Assistance**

This one sits deeper in Settings and changes how taps feel, so it's best set up **with a helper**.

- 1 Open **Settings**, then **Accessibility**** 
Two taps to get started.
- 2 Tap **Touch**, then **Touch Accommodations**** 
It's under the "Physical & Motor" heading.
- 3 Turn **Touch Accommodations** on** 
The big switch at the top turns green.
- 4 Set **Tap Assistance** to **Use Initial Touch Location**** 
This is the one that stops a jiggle from swiping.

✓ Nothing here is permanent. If it doesn't feel right, a helper can **switch it back off** in the same place.

What changes **now**.

GOOD TO KNOW The phone waits a beat

Your taps will feel a little different — here's why, and how to work with it.



The phone pauses for a moment.

That tiny wait is how it ignores the jiggle. It's working, not broken.



To tap: touch, then lift.

Lift your finger and it taps where you first landed — slide and all.



To scroll: touch, wait, then drag.

Hold a beat first, then move your finger. Swiping still works.



Two more helpers, same menu.

“Hold Duration” waits before a touch counts; “Ignore Repeat” merges shaky taps.



Turn it off fast if needed.

Triple-click the side button to toggle it off and back on.



Steady the phone, too.

Rest it on a table or your lap and brace your elbow — settings plus support work best.



Give it a day or two. Once your hand and the phone get used to each other, those **stray swipes** mostly disappear.
