

RV1: variable emitter resistance (sets bias and fuzz)