

DAY 3 – PERIPHERAL TROUBLESHOOTING

Course: Diploma in Cyber Security

Topic: Peripheral Troubleshooting

Name: HET ACHARYA

TASK 1 – USB KEYBOARD / MOUSE ISSUES

1. Keyboard or Mouse is Not Working:

The keyboard or mouse may not work when connected to the laptop.

Solution:

Unplug the device and connect it to another USB port.

2. USB Device is Not Detected:

The laptop may not detect the connected keyboard or mouse.

Solution:

Reconnect the device and restart the laptop if required.

3. Keyboard Keys Are Not Responding:

Some keyboard keys may stop responding.

Solution:

Check the keyboard connection and clean the keyboard if necessary.

4. Mouse Cursor is Not Moving:

The mouse may be connected but the cursor does not move.

Solution:

Reconnect the mouse or try another USB port.

5. Device Works Intermittently:

The keyboard or mouse may work sometimes and stop working randomly.

Solution:

Try another USB port and check whether the cable or device is damaged.

TASK 2 – BLUETOOTH HEADPHONES NOT CONNECTING

Situation:

Bluetooth headphones are not connecting to the phone.

Step 1 – Check Bluetooth

Open the phone settings and Turn on Bluetooth .

Step 2 – Check Headphones

Check headphones battery and check its on.

Step 3 – Pairing Mode

Put the headphones on Bluetooth pairing mode and check for the pairing indicator.

Step 4 – Check Available Devices

Open the Bluetooth device list and check if the headphones appear.

Step 5 – Forget and Re-pair

If the headphones is previously connected, forget/remove the device and pair it again.

Step 6 – Restart

Restart the phone and headphones, then try connecting again.

TASK 3 – EXTERNAL WEBCAM NOT DETECTED

Situation:External webcam is not detected during a Zoom call on Windows 10.

1. Check USB Connection

Check webcam USB cable is properly connected.

2. Try Another USB Port

If not detected Connect the webcam to another USB port.

3. Check Device Manager

Open Device Manager and check whether the webcam appears under Cameras or Imaging devices.

4. Check Privacy Settings

Open Windows privacy settings and check camera access is allowed.

5. Check Zoom Camera Settings

Open Zoom settings and check correct webcam is selected under the Video settings.

6. Restart / Reconnect :Disconnect the webcam, restart the computer and connect the webcam again.

TASK 4 – PRINTER SHOWING OFFLINE

Situation:

The printer is showing “Offline” on the PC.

Step 1 – Check Printer Connection

Check printer is switched ON and connected to the computer or network.

Step 2 – Open Printer Settings

Open Windows Settings and go to printer settings.

Step 3 – Select the Printer

Select the printer the showing as offline.

Step 4 – Run Troubleshooter

Use the available Windows printer troubleshooting option and follow the instructions shown on screen.

Step 5 – Check the Results

The troubleshooter checks for possible problems and may identify issues related to the printer connection, settings, driver or printer status.

Step 6 – Apply the Suggested Fix

If Windows provides a recommended solution, apply the fix and check the printer again.

CONCLUSION

In this assignment, I learned about common problems related to computer peripherals and their troubleshooting methods.

I learned how to identify and solve basic issues with USB keyboards, mice, Bluetooth headphones, and external webcams. I also learned about checking connections, device settings, drivers, privacy settings, and app permissions.

Finally, I learned how to troubleshoot a printer showing an offline status by using the Windows Troubleshooter and checking possible connection, settings, and driver-related problems.

Overall, this assign