

DAY 4 – CONNECTING AND TESTING PERIPHERALS

Course: Diploma in Cyber Security

**Topic: Connecting and Testing
Peripherals**

Name: HET ACHARYA

TASK 1 – CONNECT AND TEST USB WEBCAM

Connect a USB webcam to the computer, install any required drivers, and test it using the default Camera app

Steps: 1. Connect the Webcam

Connect the USB webcam to USB port on the computer.

2. Check the Driver

Check whether Windows automatically detects the webcam and installs the required driver.

3. Open Camera App

Open the Camera app on the computer.

4. Check the Video

Check whether the webcam video is displayed correctly.

5. Capture a Photo

Capture a photo using the Camera app to verify that the webcam is working.

Result:

The webcam was successfully connected and tested using the Camera app.

TASK 2 – SET UP AND TEST A PRINTER

Set up a local printer using USB or network connection, install the correct driver, and print a test page

Steps:

1. Connect the Printer

Connect the printer using USB or connect it to the local network.

2. Turn ON the Printer

Switch on the printer and make sure it is ready.

3. Install Driver

Install the correct printer driver if required.

4. Check Printer Settings

Open Windows printer settings and check whether the printer is detected.

5. Print Test Page

Print a test page to confirm successful installation.

Result:

The printer was successfully installed and the test page was printed.

TASK 3 – PRINTER NOT DETECTED

Situation:

The printer's USB cable is unplugged and the computer shows that the printer is not detected.

Steps:

1. Check USB Cable

First, check whether the printer's USB cable is properly connected.

2. Reconnect the Cable

Reconnect the USB cable to the printer and computer.

3. Open Device Manager

Open Windows Device Manager and check for the printer or any device with an error icon.

4. Scan for Hardware Changes

Use the **Scan for hardware changes** option in Device Manager.

5. Check Detection

Check whether Windows detects the printer after scanning.

6. Test the Printer

Try printing a test page after the printer is detected.

**USB Unplugged → Reconnect → Device Manager → Error Icon
Check → Scan for Hardware Changes → Test**

TASK 4 – WEBCAM NOT WORKING IN ZOOM

Situation:

The webcam works in the default Camera app but does not display video in Zoom.

Steps:

1. Close Other Camera Apps

Close the default Camera app and any other application that may be using the webcam.

2. Check Zoom Camera Settings

Open Zoom settings and check whether the correct webcam is selected.

3. Check Camera Permission

Check Windows privacy settings and make sure camera access is allowed.

4. Check Zoom Permission

Make sure Zoom has permission to access the camera.

5. Restart Zoom

Close Zoom completely and open it again.

6. Test the Webcam

Start a Zoom video call and check whether the webcam video is now displayed.

CONCLUSION

In this assignment, I learned how to **connect, set up and test different computer peripherals** such as webcams and printers.

I learned how to connect a **USB webcam**, check its driver and test it using the default Camera app. I also learned how to set up a printer, install the required driver and print a test page.

I also learned how to troubleshoot a **printer that is not detected** by using Windows Device Manager and the **Scan for hardware changes** option.

Finally, I learned how to troubleshoot a **webcam that works in the Camera app but not in Zoom** by checking camera settings, permissions and other applications using the webcam.

Overall, this assignment helped me understand how to properly connect, test and troubleshoot computer peripherals in a practical way.