

iron-X with Keyboard & JoyStick By TESR





Control iron-X with JoyStick



Control iron-X with JoyStick





Tx LED	Status
Blinking	Pairing
LED ON	Paired
LED OFF	Turn off or sleep



Control iron-X with JoyStick



iron-X with Keyboard control on ROS2

- You can activate keyboard to control iron-X using:
 - On first terminal, run ironx_driver:

ros2 run ironx_bringup ironx_driver

On second terminal, run teleop_twist_keyboard:

ros2 run teleop_twist_keyboard teleop_twist_keyboard

iron-X with Keyboard control on ROS2






RosGraph for Keyboard control on ROS2

• You can see the RosGraph by open new terminal and type:

rqt_graph



Contact Us

Email: tesrshop@gmail.com

Line official Account: @ion1900z

Facebook fanpage: TESR

Tel. 082-983-7768

Scan here









TESR Co., LTD

112/296 หมู่บ้าน เพอร์เฟค มาสเตอร์พีซ หมู่ที่ 2 ตำบลไทรม้า อำเภอเมืองนนทบุรี จังหวัดนนทบุรี 11000

