







Sheet: /PCB1/PCB1-Speakers and Connectors/
File: speakers.kicad_sch

Title:


Size: USLetter

Date:

Rev:

KiCad E.D.A. 9.0.6

Id: 2/10



Sheet: /PCB1/PCB1-Charging and Power Port + USB switch/
File: powerport.kicad_sch

Title:


Size: USLetter

Date:

Rev:

KiCad E.D.A. 9.0.6

Id: 11/10



Sheet: /PCB1/PCB1-Charging and Power/
File: charging_power.kicad_sch


Title:


Size: USLetter Date:

KiCad E.D.A. 9.0.6

Rev:

Id: 16/10







Sheet: /PCB1/PCB1-HDMI/
File: hdmi.kicad_sch

Title:

Size: USLetter Date:
KiCad E.D.A. 9.0.6

Rev:
Id: 19/10






Sheet: /PCB3/PCB3-USB 2.0 Bridge/
File: untitled.kicad_sch

Title:

Size: USLetter
KiCad E.D.A. 9.0.6

Date:

Rev:
Id: 10/10



Sheet: /PCB3/PCB3-PWM and Motors/
 File: pwm_motors.kicad_sch

Title:

Size: USLetter Date:
 KiCad E.D.A. 9.0.6

Rev:
 Id: 11/10