

HAL Drivers Application Programming Interface

Document Number: F8W-2005-1504

Texas Instruments, Inc. San Diego, California USA (619) 542-1200

| Version | Description | Date |
|---------|----------------------------|------------|
| 1.0 | Initial release. | 03/02/2006 |
| 1.1 | Hal sleep updates | 11/20/2006 |
| 1.2 | Updated LCD and timers API | 11/22/2006 |

TABLE OF CONTENTS

| | INTRO | DUCTION | .1 |
|-----------|------------------------------------------------------------------------------------------------------------------------------------------------|------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------|----------------------------------------------------------------|
| 1 | 1.1 Pui | RPOSE | . 1 |
| 1 | 1.2 AC | RONYMS | . 1 |
| 2. | DDIVE | RS API OVERVIEW | 2 |
| | | | |
| 2 | | ICTION CALLS | |
| | 2.1.1 | Initialization Function Calls | |
| | 2.1.2 | Service Access Function Calls | |
| _ | 2.1.3 | Callback Function Calls | |
| 4 | 2.2 SEF | VICES | . 2 |
| 3. | ADC SI | CRVICE | .3 |
| 3 | 3.1 HA | ADCINIT () | 3 |
| • | 3.1.1 | Description | |
| | 3.1.2 | Prototype | |
| | 3.1.3 | Parameter Details | |
| | 3.1.4 | Return | |
| 3 | 3.2 HA | LADCREAD () | .3 |
| | 3.2.1 | Description | . 3 |
| | 3.2.2 | Prototype | . 3 |
| | 3.2.3 | Parameter Details | |
| | 3.2.4 | Return | |
| 3 | | NSTANTS | |
| | 3.3.1 | Channels | |
| | 3.3.2 | Resolutions | .4 |
| 4. | LCD SE | RVICE | .4 |
| 4 | 4.1 HA | LCDINIT() | .4 |
| | 4.1.1 | Description | |
| | 4.1.2 | | |
| | 7.1.4 | Prototype | |
| | 4.1.3 | Prototype Paraneter Details | .4 |
| | | ** | .4 .4 |
| 4 | 4.1.3 4.1.4 | Paraneter Details | .4 .4 .4 |
| 4 | 4.1.3 4.1.4 | Paraneter Details | .4 .4 .4 .4 |
| 4 | 4.1.3 4.1.4 4.2.1 4.2.1 4.2.2 | Paraneter Details Return LCDWRITESTRING() Description Prototype | .4 .4 .4 .4 |
| 4 | 4.1.3 4.1.4 4.2.1 4.2.2 4.2.3 | Paraneter Details Return LCDWRITESTRING() Description Prototype Parameter Details | .4 .4 .4 .4 .4 |
| | 4.1.3 4.1.4 4.2.1 4.2.2 4.2.3 4.2.4 | Paraneter Details Return LCDWRITESTRING() Description Prototype Parameter Details Return | .4 .4 .4 .4 .4 |
| | 4.1.3 4.1.4 4.2.1 4.2.1 4.2.2 4.2.3 4.2.4 4.3 HA | Paraneter Details Return LCDWRITESTRING() Description Prototype Parameter Details Return LCDWRITEVALUE() | .4 .4 .4 .4 .4 .5 |
| | 4.1.3 4.1.4 4.2.1 4.2.2 4.2.3 4.2.4 4.3 HA 4.3.1 | Paraneter Details Return LCDWRITESTRING() Description Prototype Parameter Details Return LCDWRITEVALUE() Description | .4 .4 .4 .4 .4 .5 |
| | 4.1.3 4.1.4 4.2.1 4.2.2 4.2.3 4.2.4 4.3.1 4.3.1 4.3.2 | Paraneter Details Return LCDWRITESTRING() Pescription Prototype Parameter Details Return LCDWRITEVALUE() Description Prototype Prototype Prototype Prototype | .4 .4 .4 .4 .4 .5 .5 |
| 4 | 4.1.3 4.1.4 4.2.1 4.2.2 4.2.3 4.2.4 4.3.1 4.3.1 4.3.2 4.3.3 | Paraneter Details Return LCDWRITESTRING() Description Prototype Parameter Details Return LCDWRITEVALUE() Description Prototype Prototype Prototype Prameter Details | .4 .4 .4 .4 .5 .5 .5 |
| 4 | 4.1.3 4.1.4 4.2.1 4.2.2 4.2.3 4.2.4 4.3.1 HA 4.3.1 4.3.2 4.3.3 4.4 HA | Paraneter Details Return LCDWRITESTRING() Description Prototype Parameter Details Return LCDWRITEVALUE() Description Prototype Prototype Parameter Details LCDWRITEVALUE() Description LCDWRITESCREEN() | .4 .4 .4 .4 .5 .5 .5 |
| 4 | 4.1.3 4.1.4 4.2.1 4.2.2 4.2.3 4.2.4 4.3.1 HA 4.3.1 4.3.2 4.3.3 4.4 HA 4.4.1 | Paraneter Details Return LCDWRITESTRING() Description Prototype Parameter Details Return LCDWRITEVALUE() Description Prototype Prototype Prototype Parameter Details LCDWRITESCREEN() Description | .4 .4 .4 .4 .5 .5 .5 .5 |
| 4 | 4.1.3 4.1.4 4.2.1 4.2.2 4.2.3 4.2.4 4.3 HA 4.3.1 4.3.2 4.3.3 4.4 HA 4.4.1 4.4.2 | Paraneter Details Return LCDWRITESTRING() Description Prototype Parameter Details Return LCDWRITEVALUE() Description Prototype Parameter Details LCDWRITESCREEN() Description Prototype Prototype Prototype Prototype Prototype Prototype Prototype Prototype Prototype | .4 .4 .4 .4 .5 .5 .5 .5 |
| 4 | 4.1.3 4.1.4 4.2.1 4.2.2 4.2.3 4.2.4 4.3.1 HA 4.3.1 4.3.2 4.3.3 4.4 HA 4.4.1 | Paraneter Details Return LCDWRITESTRING() Prototype Parameter Details Return LCDWRITEVALUE() Description Prototype Parameter Details LCDWRITESCREEN() Description Prototype Parameter Details LCDWRITESCREEN() Description Prototype Parameter Details LCDWRITESCREEN() Prototype Parameter Details | .4 .4 .4 .4 .5 .5 .5 .5 .5 |
| 4 | 4.1.3 4.1.4 4.2.1 4.2.2 4.2.3 4.2.4 4.3.1 4.3.2 4.3.3 4.4 HA 4.4.1 4.4.2 4.4.3 4.4.4 | Paraneter Details Return LCDWRITESTRING() Description Prototype Parameter Details Return LCDWRITEVALUE() Description Prototype Parameter Details LCDWRITESCREEN() Description Prototype Parameter Details LCDWRITESCREEN() Description Prototype Parameter Details Return | .4 .4 .4 .4 .5 .5 .5 .5 .5 |
| 4 | 4.1.3 4.1.4 4.2.1 4.2.2 4.2.3 4.2.4 4.3.1 4.3.2 4.3.3 4.4 HA 4.4.1 4.4.2 4.4.3 4.4.4 | Paraneter Details Return LCDWRITESTRING() Prototype Parameter Details Return LCDWRITEVALUE() Description Prototype Parameter Details LCDWRITESCREEN() Description Prototype Parameter Details LCDWRITESCREEN() Description Prototype Parameter Details LCDWRITESCREEN() Prototype Parameter Details | .4 .4 .4 .5 .5 .5 .5 .5 .5 .5 |
| 4 | 4.1.3 4.1.4 4.2.1 4.2.2 4.2.3 4.2.4 4.3.1 4.3.2 4.3.3 4.4 HA 4.4.1 4.4.2 4.4.3 4.4.4 4.5 HA | Paraneter Details Return LCDWRITESTRING() Description Prototype Parameter Details Return LCDWRITEVALUE() Description Prototype Parameter Details LCDWRITESCREEN() Description Prototype Parameter Details LCDWRITESCREEN() Description Prototype Parameter Details LCDWRITESCREEN() Description Prototype Parameter Details Return LCDWRITESTRINGVALUE() | .4 .4 .4 .4 .5 .5 .5 .5 .5 .5 .5 |
| 4 | 4.1.3 4.1.4 4.2.1 4.2.2 4.2.3 4.2.4 4.3.1 4.3.2 4.3.3 4.4 HA 4.4.1 4.4.2 4.4.3 4.4.4 4.5 HA 4.5.1 | Parameter Details. Return LCDWRITESTRING() Description Prototype Parameter Details. Return LCDWRITEVALUE() Description Prototype Parameter Details LCDWRITESCREEN() Description Prototype Parameter Details. LCDWRITESCREEN() Description Prototype Parameter Details. Return LCDWRITESTRINGVALUE() Description | .4 .4 .4 .4 .5 .5 .5 .5 .5 .5 .5 |

| | | T W G W W | |
|----|--------|-----------------------------|------|
| | | LLCDWRITESTRINGVALUEVALUE() | |
| | 4.6.1 | Description | |
| | 4.6.2 | Prototype | |
| | 4.6.3 | Parameter Details | |
| | 4.6.4 | Return | |
| | 4.7 HA | LLCDDisplayPercentBar() | |
| | 4.7.1 | Description | 7 |
| | 4.7.2 | <i>Prototype</i> | 2 |
| | 4.7.3 | Parameter Details | 2 |
| | 4.7.4 | Return | |
| | | NSTANTS | |
| | 4.8.1 | Options | |
| | | | |
| 5. | LED SE | ERVICE | 7 |
| | 5.1 HA | LLEDINIT() | _ |
| | | | |
| | 5.1.1 | Description | |
| | 5.1.2 | Prototype | |
| | 5.1.3 | Parameter Details | |
| | 5.1.4 | Return | |
| | | LLEDSET() | |
| | 5.2.1 | Description | |
| | 5.2.2 | Prototype | 8 |
| | 5.2.3 | Parameter Details | 8 |
| | 5.2.4 | Return | 8 |
| | 5.3 HA | LLEDBLINK() | |
| | 5.3.1 | Description | |
| | 5.3.2 | Prototype | |
| | 5.3.3 | Parameter Details | |
| | 5.3.4 | Return | |
| | | | |
| | | LLEDGETSTATE() | |
| | 5.4.1 | Description | |
| | 5.4.2 | Prototype | |
| | 5.4.3 | Parameter Details | |
| | 5.4.4 | Return | |
| | 5.5 HA | LLEDENTERSLEEP() | 9 |
| | 5.5.1 | Description | ٠. ٩ |
| | 5.5.2 | Prototype | 9 |
| | 5.5.3 | Parameter Details | 9 |
| | 5.5.4 | Return | 9 |
| | 5.6 HA | LLEDEXITSLEEP() | 9 |
| | 5.6.1 | Description | 9 |
| | 5.6.2 | Prototype | |
| | 5.6.3 | Parameter Details | |
| | 5.6.4 | Return | |
| | | NSTANTS | |
| | 5.7.1 | LEDs | |
| | | | |
| | 5.7.2 | Modes | 10 |
| 6. | KEY SI | ERVICE | 1(|
| | 6.1 HA | LKEYINIT() | 1/ |
| | | | |
| | 6.1.1 | Description | |
| | 6.1.2 | Prototype | |
| | 6.1.3 | Parameter Details | |
| | 6.1.4 | Return | |
| | 6.2 HA | I.KEYCONFIG() | 1(|

| 6.2.1 | Description | |
|----------|-------------------------|----|
| 6.2.2 | Prototype | 11 |
| 6.2.3 | Parameter Details | 11 |
| 6.2.4 | Return | 11 |
| 6.3 H | ALKEYREAD() | 11 |
| 6.3.1 | Description | 11 |
| 6.3.2 | <i>Prototype</i> | 11 |
| 6.3.3 | Parameter Details | 11 |
| 6.3.4 | Return | 11 |
| 6.4 H | ALKEYENTERSLEEP() | 11 |
| 6.4.1 | Description | 11 |
| 6.4.2 | Prototype | 11 |
| 6.4.3 | Parameter Details | 11 |
| 6.4.4 | Return | 11 |
| 6.5 H | ALKEYEXITSLEEP() | 12 |
| 6.5.1 | Description | |
| 6.5.2 | Prototype | |
| 6.5.3 | Parameter Details | |
| 6.5.4 | Return | |
| 6.6 H | ALKEYPOLL() | 12 |
| 6.6.1 | Description | |
| 6.6.2 | Prototype | |
| 6.6.3 | Parameter Details | |
| 6.6.4 | Return | |
| 6.7 H | ALKEYPRESSED() | 12 |
| 6.7.1 | Description | |
| 6.7.2 | <i>Prototype</i> | |
| 6.7.3 | Parameter Details | |
| 6.7.4 | Return | |
| 6.8 C | ONSTANT | 12 |
| 6.8.1 | Keys | |
| 6.8.2 | Joystick | |
| 6.8.3 | States | |
| 7. SLEEI | P SERVICE | 12 |
| | | |
| 7.1 H | ALSLEEP() | 13 |
| 7.1.1 | Description | |
| 7.1.2 | Prototype | |
| 7.1.3 | Parameter Details | |
| 7.1.4 | Return | |
| 7.2 H | ALSLEEPWAIT() | 14 |
| 7.2.1 | Description | |
| 7.2.2 | Prototype | |
| 7.2.3 | Parameter Details | 14 |
| 7.2.4 | Return | 14 |
| 8. TIME | R SERVICE | 14 |
| | | |
| | PERATION MODES | |
| | HANNELS | |
| | NTERRUPTS/CHANNEL MODES | |
| | ALTIMERINIT () | |
| 8.4.1 | Description | |
| 8.4.2 | Prototype | |
| 8.4.3 | Parameter Details | |
| 8.4.4 | Return | |

| 8.5 HAL | TimerConfig() | |
|-----------|------------------------|----|
| 8.5.1 | Description | 15 |
| 8.5.2 | Prototype | 15 |
| 8.5.3 | Parameter Details | 15 |
| 8.5.4 | Return | 15 |
| 8.6 HAL | TIMERSTART () | |
| 8.6.1 | Description | |
| 8.6.2 | Prototype | |
| 8.6.3 | Parameter Details | |
| 8.6.4 | Return | |
| | TIMERSTOP() | |
| 8.7.1 | Description | |
| 8.7.2 | Prototype | |
| | ** | |
| 8.7.3 | Parameter Details | |
| 8.7.4 | Return | |
| | TIMERTICK() | |
| 8.8.1 | Description | |
| 8.8.2 | Prototype | |
| 8.8.3 | Parameter Details | |
| 8.8.4 | Return | |
| | TIMERINTERRUPTENABLE() | |
| 8.9.1 | Description | |
| 8.9.2 | Prototype | |
| 8.9.3 | Parameter Details | |
| 8.9.4 | Return | 17 |
| 8.10 Con | ISTANTS | |
| 8.10.1 | Timer ID | 17 |
| 8.10.2 | Channels | 17 |
| 8.10.3 | Channel Modes | 17 |
| 8.10.4 | Operation Modes | 18 |
| 8.10.5 | Prescale | 18 |
| 8.10.6 | Status | 18 |
| O. UART S | ERVICE | 1(|
| | | |
| 9.1 HAL | UARTINIT () | |
| 9.1.1 | Description | |
| 9.1.2 | Prototype | 19 |
| 9.1.3 | Parameter Details | |
| 9.1.4 | Return | 19 |
| 9.2 HAL | UARTOPEN() | |
| 9.2.1 | Description | |
| 9.2.2 | Prototype | 19 |
| 9.2.3 | Parameter Details | 19 |
| 9.2.4 | Return | 21 |
| 9.3 HAL | UARTCLOSE () | 21 |
| 9.3.1 | Description | 21 |
| 9.3.2 | Prototype | 21 |
| 9.3.3 | Parameter Details | |
| 9.3.4 | Return | 2 |
| 9.4 HAL | UARTREAD () | |
| 9.4.1 | Description | |
| 9.4.2 | Prototype | |
| 9.4.3 | Parameter Details | |
| 9.4.4 | Return | |
| | UARTWrite () | |

| 9.5.1 | Description | 22 |
|----------|-------------------------|----|
| 9.5.2 | Prototype | 22 |
| 9.5.3 | Parameter Details | 22 |
| 9.5.4 | Return | 22 |
| 9.6 HAI | LUARTIOCTL () | 22 |
| 9.6.1 | Description | 22 |
| 9.6.2 | Prototype | 22 |
| 9.6.3 | Parameter Details | 22 |
| 9.6.4 | Return | 23 |
| 9.7 HAI | LUARTPOLL() | 23 |
| 9.7.1 | Description | 23 |
| 9.7.2 | Prototype | 23 |
| 9.7.3 | Parameter Details | 23 |
| 9.7.4 | Return | 23 |
| 9.8 HAI | L_UART_RxBuffLen() | 23 |
| 9.8.1 | Description | 23 |
| 9.8.2 | Prototype | 23 |
| 9.8.3 | Parameter Details | 24 |
| 9.8.4 | Return | 24 |
| 9.9 HAI | L_UART_TxBuffLen() | 24 |
| 9.9.1 | Description | 24 |
| 9.9.2 | Prototype | 24 |
| 9.9.3 | Parameter Details | 24 |
| 9.9.4 | Return | 24 |
| 9.10 HAI | L_UART_FLOWCONTROLSET() | 24 |
| 9.10.1 | Description | 24 |
| 9.10.2 | Prototype | 24 |
| 9.10.3 | Parameter Details | 24 |
| 9.10.4 | Return | 24 |
| 9.11 Con | NSTANTS | 24 |
| 9.11.1 | UART Ports | 24 |
| 9.11.2 | Baud Rates | 25 |
| 9.11.3 | Parity | 25 |
| 9.11.4 | Stop Bits | 25 |
| 9.11.5 | Status | |
| 9.11.6 | Callback Events | 25 |
| | | |

1. Introduction

1.1 Purpose

This document describes the application programming interface for HAL Drivers. The API provides application the interface to access timers, GPIO, UART, and ADC. This is a platform independent API that provides a superset of features for each service. Not all features will be available for all platforms.

1.2 Acronyms

| ADC | Analog to Digital Conversion |
|------|-------------------------------------|
| API | Application Programming Interface. |
| CD | Carrier Detect |
| CTS | Clear To Send |
| DSR | Data Set Ready |
| DTR | Data Terminal Ready |
| GPIO | General Purpose Input Output |
| HAL | Hardware Abstract Layer |
| MAC | Medium Access Control. |
| OSAL | Operating System Abstraction Layer. |
| RI | Ring Indicator |
| RTS | Ready To Send |

2. Drivers API Overview

2.1 Function Calls

2.1.1 Initialization Function Calls

These function calls are used to initialize a service and /or to setup optional parameters for platform-specific data. Initialization functions are often called at the beginning stage when the device power up.

2.1.2 Service Access Function Calls

These function calls can directly access hardware registers to get/set certain value of the hardware (i.e. ADC) or control the hardware components (i.e. LED).

2.1.3 Callback Function Calls

These functions must be implemented by the application and are used to pass events that generated by the hardware (interrupts, counters, timers...) or by polling mechanism (UART poll, Timer poll...) to upper layer. Data accessed through callback function parameters (such as a pointer to data) are only valid for the execution of the function and should not be considered valid when the function returns. If these functions execute in the context of the interrupt, it must be efficient and not perform CPU-intensive operations or use critical sections.

2.2 Services

HAL drivers provide Timer, GPIO, LEDs, Switched, UART, and ADC service for MAC and upper layers. Not all the features in the service are available in every platform. Features in each service can be configured for different platform through initialization function.

3. ADC Service

This service supports 8, 10, and 14-bit analog to digital conversion on 8 channels (0-7)

3.1 HalAdcInit ()

3.1.1 Description

This ADC initialization function is called once at the startup. This function has to be called before any other ADC functions can be called. It enables ADC to be initialized with both required and optional parameters.

3.1.2 Prototype

```
void HalAdcInit (void)
```

3.1.3 Parameter Details

None.

3.1.4 Return

None.

3.2 HalAdcRead ()

3.2.1 Description

This function reads and returns the value of the ADC conversion at specified channel and resolution.

3.2.2 Prototype

3.2.3 Parameter Details

```
channel – input channels (<u>Check Channels Table</u>)resolution – resolution of the conversion. (<u>Check Resolutions Table</u>)
```

3.2.4 Return

Return 16-bit value of the conversion at the given channel and resolution.

3.3 Constants

3.3.1 Channels

| Parameter | Desription |
|-------------------|-----------------|
| HAL_ADC_CHANNEL_0 | Input channel 0 |
| HAL_ADC_CHANNEL_1 | Input channel 1 |
| HAL_ADC_CHANNEL_2 | Input channel 2 |
| HAL ADC CHANNEL 3 | Input channel 3 |

| HAL_ADC_CHANNEL_4 | Input channel 4 |
|-------------------|-----------------|
| HAL_ADC_CHANNEL_5 | Input channel 5 |
| HAL_ADC_CHANNEL_6 | Input channel 6 |
| HAL_ADC_CHANNEL_7 | Input channel 7 |

3.3.2 Resolutions

| Parameter | Desription |
|-----------------------|-------------------|
| HAL_ADC_RESOLUTION_8 | 8-bit resolution |
| HAL_ADC_RESOLUTION_10 | 10-bit resolution |
| HAL_ADC_RESOLUTION_12 | 12-bit resolution |
| HAL_ADC_RESOLUTION_14 | 14-bit resolution |

4. LCD Service

This service allows writing text on the LCD. Not every board supports LCD.

4.1 HalLcdInit()

4.1.1 Description

This initialization function is called once at the startup. This function has to be called before any other LCD function can be called. It enables LCD to be initialized with both required and optional parameters.

4.1.2 Prototype

void HalLcdInit (void);

4.1.3 Paraneter Details

None.

4.1.4 Return

None.

4.2 HalLcdWriteString()

4.2.1 Description

This routine writes a string to the LCD.

4.2.2 Prototype

4.2.3 Parameter Details

str – pointer to the string that will be displayed on the LCD. Max length of the string is defined under HAL_LCD_MAX_CHARS. If the length is greater than HAL_LCD_MAX_CHARS, then only HAL_LCD_MAX_CHARS will be displayed.

option – option for the string to be displayed on the LCD. (Check Options table).

4.2.4 Return

None.

4.3 HalLcdWriteValue()

4.3.1 Description

This routine writes a 32-bit value to the LCD.

4.3.2 Prototype

4.3.3 Parameter Details

```
value – value that will be displayed on the LCD.
```

radix – representation of the value. It can be 8, 10 or 16. (Octal, Decimal, or Hex)

option – option for the value to be displayed on the LCD. (Check Options table)

4.4 HalLcdWriteScreen()

4.4.1 Description

This routine writes 2 lines of text on the LCD display.

4.4.2 Prototype

4.4.3 Parameter Details

```
Line1 – pointer to the 1<sup>st</sup> string that will be displayed on the LCD
```

Line2 – pointer to the 2nd string that will be displayed on the LCD

4.4.4 Return

None.

4.5 HalLcdWriteStringValue()

4.5.1 Description

This routine writes a string followed by a 16-bit value on the specified line number on the LCD display.

4.5.2 Prototype

```
void HalLcdWriteStringValue( char *title,
```

```
uint16 value,
uint8 format,
uint8 line );
```

4.5.3 Parameter Details

```
title – string that will be displayed on the LCD display.
```

value – value that will be displayed following the "title".

format – format of the value that will be displayed. It can be 8, 10, and 16 (Octal, Decimal and Hex)

line – the line number where the string (title and value) will be displayed on the LCD display.

```
Example: To display "Count: 180" on line 2 of the LCD display HalLcdWriteStringValue ("Count:", 180, 10, 2);
```

4.5.4 Return

None.

4.6 HalLcdWriteStringValueValue()

4.6.1 Description

Write two 16-bit values back to back on the specified line on the LCD display underneath the a title.

4.6.2 Prototype

4.6.3 Parameter Details

```
title – string that will be displayed on the LCD display.
```

value1 – 1st value that will be displayed after the "title".

format1 – format for the "value1". It can be 8, 10, and 16 (Octal, Decimal, and Hex).

value2 – 2nd value that will be displayed after "value1".

format2 – format for the "value2". It can be 8, 10, and 16 (Octal, Decimal, and Hex).

line – line number where the string (title, value1 and value2) will be displayed on the LCD display.

```
Example: HalLcdWriteStringValueValue ("Test: ", 2, 10, 30, 10, 1);
Test: 2 30
```

4.6.4 Return

None.

4.7 HalLcdDisplayPercentBar()

4.7.1 Description

Simulating a percentage bar on the LCD with the percentage in numerical figure in the middle of the bar.

4.7.2 Prototype

4.7.3 Parameter Details

```
title – string that will be displayed on the 1st line of the LCD display
```

value - percentage value that will be displayed in the middle of the bar

4.7.4 Return

None.

4.8 Constants

4.8.1 Options

| Option | Description |
|----------------|---------------------------------------|
| HAL_LCD_LINE_1 | Display the text on line 1 of the LCD |
| HAL_LCD_LINE_2 | Display the text on line 2 of the LCD |

5. LED Service

This service allows LEDs to be controlled in different ways. LED service supports ON, OFF, TOGGLE, FLASH and BLINK. Not all platforms support these modes.

5.1 HalLedInit()

5.1.1 Description

This LED initialization function is called once at the startup. This function has to be called before any other LED function can be called. It enables LED to be initialized with both required and optional parameters.

5.1.2 Prototype

```
void HallEDInit (void);
```

5.1.3 Parameter Details

None.

5.1.4 Return

None.

5.2 HalLedSet()

5.2.1 Description

This function will set the given LEDs ON, OFF, BLINK, FLASH, or TOGGLE. If BLINK and FLASH mode are used, a set of default parameters will be used. To customize these parameters, HalLedBlink() has to be used.

5.2.2 Prototype

```
void HalLedSet (uint8 led, uint8 mode);
```

5.2.3 Parameter Details

```
led – bit mask of leds to be turned ON (<u>See LEDs Table</u>)mode – new mode for the leds. (<u>See Modes Table</u>)
```

5.2.4 Return

None.

5.3 HalLedBlink()

5.3.1 Description

This function will blink the given LEDs based on the provided parameters.

5.3.2 Prototype

5.3.3 Parameter Details

```
leds – bit mask of leds to be blinked (See LEDs Table)
numBlinks – number of times the LED will blink
percent – percentage of the cycle that is ON.
period – time in milliseconds of one ON/OFF cycle.
```

5.3.4 Return

None.

5.4 HalLedGetState()

5.4.1 Description

This function returns the current state of the leds.

5.4.2 Prototype

uint8 HalLedGetState (void);

5.4.3 Parameter Details

None.

5.4.4 Return

8-bit contains the current state of the leds. Each bit indicates the corresponding led status.

5.5 HalLedEnterSleep()

5.5.1 Description

This function stores the current state of the leds and turn off all the leds to conserve power. It also sets a global state variable indicating sleep mode has been entered. This global state variable will stop the interrupt from processing the leds during while in sleep mode.

5.5.2 Prototype

void HalLedEnterSleep (void);

5.5.3 Parameter Details

None.

5.5.4 Return

None.

5.6 HalLedExitSleep()

5.6.1 Description

This function restores the original state of the leds as before it entering sleep mode

5.6.2 Prototype

void HalLedExitSleep (void);

5.6.3 Parameter Details

None.

5.6.4 Return

None.

5.7 Constants

5.7.1 LEDs

| LED | Description |
|-----------|-------------|
| HAL_LED_1 | LED 1 |
| HAL_LED_2 | LED 2 |

| HAL_LED_3 | LED 3 |
|-------------|----------|
| HAL_LED_4 | LED 4 |
| HAL_LED_ALL | All LEDs |

5.7.2 Modes

| Mode | Description |
|---------------------|------------------|
| HAL_LED_MODE_OFF | Turn OFF the LED |
| HAL_LED_MODE_ON | Turn ON the LED |
| HAL_LED_MODE_BLINK | BLINK the LED |
| HAL_LED_MODE_FLASH | FLASH the LED |
| HAL_LED_MODE_TOGGLE | TOGGLE the LED |

6. KEY Service

This service provides services for keys, switches and joysticks. The service can be polling or interrupt driven. A callback function has to be registered in order for the service to inform the application the status of the keys/switches/joysticks.

6.1 HalKeyInit()

6.1.1 Description

This initialization function is called once at the startup. This function has to be called before any other function that use keys/switches/joysticks can be called. It enables Keys/switches/joysticks to be initialized with both required and optional parameters.

6.1.2 Prototype

void HalKeyInit (void *init);

6.1.3 Parameter Details

None.

6.1.4 Return

None.

6.2 HalKeyConfig()

6.2.1 Description

This function is used to configure the Keys/Switches/Joysticks service as polling or interrupt driven. It also setup a callback function for the service. If interrupt is not used, polling starts automatically after 100ms. Keys/switches/joystick will be polled every 100ms. If interrupt is used, an ISR will handle the case. There is a delay of 25ms after the interrupt occurs to eliminate de-bounce.

6.2.2 Prototype

6.2.3 Parameter Details

interruptEnable – TRUE or FALSE. Enable or disable the interrupt. If interrupt is disabled, the keys/switches/joysticks will be polled. Otherwise, the keys/switches/joysticks will be on interrupt.

cback – this call back occurs when a key, switch or joystick is active. If the callback is set to NULL, the event will not be handled.

```
typedef void (halGpioCback_t) (uint8 key, uint8 state);
```

key – the key/switch/joystick that will cause the callback when it's triggered. (Check Keys table)

state – current state of the key/switch/joystick that cause the callback. (Check States table)

6.2.4 Return

None.

6.3 HalKeyRead()

6.3.1 Description

This function is used to read the current state of the Key/Switch/Joystick. If the Key Service is set to polling, his function will be called by the Hal Driver Task every 100ms. If the Key Service is set to interrupt driven, this function will be called by the Hal Driver Task 25ms after the interrupt occurs. If a callback is registered during HalKeyConfig(), that callback will be sent back to the application with the new status of the keys. Otherwise, there will be no further action.

6.3.2 Prototype

```
uint8 HalKeyRead ( void );
```

6.3.3 Parameter Details

None.

6.3.4 Return

Return the bit mask state of the keys. (Check Keys table)

6.4 HalKeyEnterSleep()

6.4.1 Description

This function sets a global state variable indicating sleep mode has been entered. This global state variable is used to stop the interrupt from processing the keys during sleep mode.

6.4.2 Prototype

```
void HalKeyEnterSleep (void);
```

6.4.3 Parameter Details

None.

6.4.4 Return

None.

6.5 HalKeyExitSleep()

6.5.1 Description

This function set a global state variable indicating sleep mode has been exit. It also processes those keys that are stored by the key interrupt.

6.5.2 Prototype

```
void HalKeyExitSleep (void);
```

6.5.3 Parameter Details

None.

6.5.4 Return

None.

6.6 HalKeyPoll()

6.6.1 Description

This routine is used internally by hal driver

6.6.2 Prototype

void HalKeyPoll (void);

6.6.3 Parameter Details

None.

6.6.4 Return

None.

6.7 HalKeyPressed()

6.7.1 Description

This routine is used internally by hal sleep

6.7.2 Prototype

```
bool HalKeyPressed( void );
```

6.7.3 Parameter Details

None.

6.7.4 Return

None.

6.8 Constant

6.8.1 Keys

| Key | Description |
|--------------|-------------------|
| HAL_KEY_SW_1 | Key #1 is pressed |
| HAL_KEY_SW_2 | Key #2 is pressed |
| HAL_KEY_SW_3 | Key #3 is pressed |
| HAL_KEY_SW_4 | Key #4 is pressed |
| HAL_KEY_SW_5 | Key #5 is pressed |
| HAL_KEY_SW_6 | Key #6 is pressed |

6.8.2 Joystick

| Key | Description |
|----------------|--------------------|
| HAL_KEY_UP | Joystick is up |
| HAL_KEY_RIGHT | Joystick is down |
| HAL_KEY_CENTER | Joystick is center |
| HAL_KEY_LEFT | Joystick is left |
| HAL_KEY_DOWN | Joystick is down |

6.8.3 States

| State | Description |
|----------------------|------------------------------|
| HAL_KEY_STATE_NORMAL | The key is press normally |
| HAL_KEY_STATE_SHIFT | The key is shift and pressed |

7. Sleep Service

This service is part of the power saving mechanism. Osal uses these routines to exercise low power mode when POWER_SAVING symbol is compiled.

7.1 HalSleep()

7.1.1 Description

This routine is called from the OSAL task loop through the OSAL interface to set the low power mode of the MAC.

7.1.2 Prototype

void halSleep(uint16 osal_timeout)

7.1.3 Parameter Details

osal_timeout – The next OSAL timer timeout. This will be used to determine how long the MAC needs to sleep or awake.

7.1.4 Return

13

None.

7.2 HalSleepWait()

7.2.1 Description

This routine performs a blocking wait.

7.2.2 Prototype

void halSleepWait(uint16 duration)

7.2.3 Parameter Details

duration – duration of the blocking in micro seconds

7.2.4 Return

None.

8. Timer Service

This service supports up to four hardware timers, two 8-bit timers and two 16-bit timers.

8.1 Operation Modes

Timer service supports Normal and CTC (Clear Timer on Compare) mode. In Normal mode, the Timer/Counter is always up, and no Timer/Counter clear is performed. The Timer/Counter simply overruns when it passes its maximum and then restarts from zero again. In CTC mode, the Timer/Counter will be cleared to zero when the Timer/Counter matches the given value.

8.2 Channels

Timer service has up to 3 channels output compare and 1 channel for input capture or overflow channel mode for 16bit timers. For 8bit timers, the Timer Service has 1 channel for output capture or overflow channel mode.

8.3 Interrupts/Channel Modes

Timer service supports 3 interrupt sources, Overflow, Output Compare, and Input Capture. However, only 16bit timers support Input Capture.

8.4 HalTimerInit ()

8.4.1 Description

This timer initialization function is called once at the startup. It should be called before any other timer function can be called. It allows hardware timers to be initialized with both required and optional parameters.

8.4.2 Prototype

void HalTimerInit (void)

8.4.3 Parameter Details

None.

8.4.4 Return

None.

8.5 HalTimerConfig()

8.5.1 Description

This function allows the channels to be configured in different modes.

8.5.2 Prototype

```
halTimerStatus_t HalTimerConfig ( uint8 timerId, uint8 opMode, uint8 channel, uint8 channelMode, bool intEnable, halTimerCBack_t cback);
```

8.5.3 Parameter Details

timerId - HAL_TIMER_X, identification of the timer. Different processors support different number of timers. (See TimerId Table)

opMode – Operation Mode, can be Normal or CTC (See Operation Modes Table)

channel – Channel to be configured. (See Channels Table)

channelMode – The channel mode, Input Capture Mode, Output Compare Mode or Overflow Mode. (<u>See Channel Modes Table</u>)

intEnable - TRUE or FALSE - Enable / Disable the interrupt

cback – pointer to the callback function. Callback function is used to inform the application when every there is an interrupt occurs.

timerId – HAL_TIMER_X, identification of the timer. Different processors support different number of timers. (See TimerId Table)

channel – the channel where the interrupt occurs. (See Channels Table)

channelMode - Interrupt source of the event.

8.5.4 Return

Status of the configuration. (See Status Table)

8.6 HalTimerStart ()

8.6.1 Description

This function starts the timer/counter with the operation mode, channel, channel mode, prescale that are provided by HalTimerConfig(). In other words, HalTimerConfig() has to be called before HalTimerStart() is called. In case of polling, timer ticks are updated by the Hal driver task calling HalTimerTick(). In case timer interrupt is used, timer ticks are updated by the interrupt every time an interrupt occurs.

8.6.2 Prototype

uint8 HalTimerStart (uint8 timerId, uint32 timePerTick);

8.6.3 Parameter Details

timerId – HAL_TIMER_X, identification of the timer. Different processors support different number of timers. (See TimerId Table)

timerPerTick - number of micro sec per tick

8.6.4 Return

If the Timer Service is not configured, HAL_TIMER_NOT_CONFIGURED will be returned. Otherwise, HAL_TIMER_OK will be returned. (See Status Table)

8.7 HalTimerStop()

8.7.1 Description

This function is called to stop a timer/counter.

8.7.2 Prototype

```
uint8 HalTimerStop (uint8 timerId);
```

8.7.3 Parameter Details

timerId - HAL_TIMER_X, identification of the timer that will be stopped. (See Timer ID Table)

8.7.4 Return

If the timerId is not valid, HAL_TIMER_INVALID_ID will be returned. Otherwise, HAL_TIMER_OK will be returned. (See Status Table)

8.8 HalTimerTick()

8.8.1 Description

This function is called by the Hal Driver task when the interrupt is disabled in order to create a tick for the application. To use HalTimerTick(), Timer Service has to be configured using HalTimerConfig() with intEnable set to FALSE before calling HalTimerTick(). HalTimerTick() will send back to the application using the provided callback function at every tick. The duration of the tick is setup using the information provided by HalTimerConfig().

8.8.2 Prototype

```
void HalTimerTick (void);
```

8.8.3 Parameter Details

None.

8.8.4 Return

None.

8.9 HalTimerInterruptEnable()

8.9.1 Description

This function will enable, disable timer interrupt of the timerId and channelMode.

8.9.2 Prototype

uint8 HalTimerInterruptEnable (uint8 timerId,

uint8 channelMode,
bool enable);

8.9.3 Parameter Details

timerId – HAL_TIMER_X, identification of the timer. Different processors support different number of timers. (See TimerId Table)

channelMode – The channel mode, Input Capture Mode, Output Compare Mode or Overflow Mode. (See Channel Modes Table)

enable - TRUE or FALSE

8.9.4 Return

If the timerId is not valid, HAL_TIMER_INVALID_ID will be returned. Otherwise, HAL_TIMER_OK will be returned. (See Status Table)

8.10 Constants

8.10.1 Timer ID

| ID | Description | |
|-------------|--------------------------------------------------------------|--|
| HAL_TIMER_0 | 8-bit timer ID | |
| HAL_TIMER_1 | 16-bit timer ID - this is MAC timer and not supported by HAL | |
| HAL_TIMER_2 | 2 8-bit timer ID | |
| HAL_TIMER_3 | 16-bit timer ID | |

8.10.2 Channels

| Channel | Description |
|--------------------------|----------------------|
| HAL_TIMER_CHANNEL_SINGLE | Single Channel Timer |
| HAL_TIMER_CHANNEL_A | Timer Channel A |
| HAL_TIMER_CHANNEL_B | Timer Channel B |
| HAL_TIMER_CHANNEL_C | Timer Channel C |

8.10.3 Channel Modes

| Channel Mode | Description |
|----------------------------------|---------------------|
| HAL_TIMER_CH_MODE_INPUT_CAPTURE | Input Capture Mode |
| HAL_TIMER_CH_MODE_OUTPUT_COMPARE | Output Compare Mode |
| HAL_TIMER_CH_MODE_OVERFLOW | Overflow Mode |

8.10.4 Operation Modes

| Operation Mode | Description |
|-----------------------|-------------------------------------------------------------------------------------------------------------------|
| HAL_TIMER_MODE_NORMAL | In Normal Mode, there is no counter clear performed. If the counter passes the max, it will restart again at zero |
| HAL_TIMER_MODE_CTC | In CTC Mode, the counter is cleared to zero when the counter matches with the specified value. |

8.10.5 Prescale

| Prescale – 8bit | Description |
|------------------------|--------------------------|
| HAL_TIMER_8_TC_STOP | No clock, timer stopped |
| HAL_TIMER_8_TC_DIV1 | No clock pre-scaling |
| HAL_TIMER_8_TC_DIV8 | Clock pre-scaled by 8 |
| HAL_TIMER_8_TC_DIV32 | Clock pre-scaled by 32 |
| HAL_TIMER_8_TC_DIV64 | Clock pre-scaled by 64 |
| HAL_TIMER_8_TC_DIV128 | Clock pre-scaled by 128 |
| HAL_TIMER_8_TC_DIV256 | Clock pre-scaled by 256 |
| HAL_TIMER_8_TC_DIV1024 | Clock pre-scaled by 1024 |

| Prescale – 16bit | Description |
|-------------------------|-----------------------------------|
| HAL_TIMER_16_TC_STOP | No clock, timer stopped |
| HAL_TIMER_16_TC_DIV1 | No clock pre-scaling |
| HAL_TIMER_16_TC_DIV8 | Clock pre-scaled by 8 |
| HAL_TIMER_16_TC_DIV64 | Clock pre-scaled by 64 |
| HAL_TIMER_16_TC_DIV256 | Clock pre-scaled by 256 |
| HAL_TIMER_16_TC_DIV1024 | Clock pre-scaled by 1024 |
| HAL_TIMER_16_TC_EXTFE | External clock (T2), falling edge |
| HAL_TIMER_16_TC_EXTRE | External clock (T2), rising edge |

8.10.6 Status

| Status | Description |
|--------------|-------------|
| HAL_TIMER_OK | OK status |

| HAL_TIMER_NOT_OK | NOT OK status |
|---------------------------|-----------------------------------------|
| HAL_TIMER_PARAMS_ERROR | Parameters are mismatched or no correct |
| HAL_TIMER_NOT_CONFIGURED | Timer is not configured |
| HAL_TIMER_INVALID_ID | Invalid Timer ID |
| HAL_TIMER_INVALID_CH_MODE | Invalid channel mode |
| HAL_TIMER_INVALID_OP_MODE | Invalid operation mode |

9. UART Service

This service configures several things in the UART such as Baud rate, flow control, CTS, RTS, DSR, DTR, CD, RI...etc. It also reports framing and overrun errors.

9.1 HalUARTInit ()

9.1.1 Description

This UART initialization function is called once at the startup. This function has to be called before any other UART function can be called. It enables UART to be initialized with both required and optional parameters.

9.1.2 Prototype

```
void HalUARTInit (void)
```

9.1.3 Parameter Details

None

9.1.4 Return

None

9.2 HalUARTOpen ()

9.2.1 Description

This function opens a port based on the configuration that is provided. A callback function is also registered so events can be handled correctly.

9.2.2 Prototype

9.2.3 Parameter Details

```
uint16 baudRate;
bool flowControl;
uint16 flowControlThreshold;
uint8 idleTimeout;
uint16 rx;
uint16 tx;
bool intEnable;
uint32 rxChRvdTime;
halUARTCBack_t callBackFunc;
}halUARTCfg_t;
```

config.configured – Set by the function when the port is setup correctly and read to be used.

config.baudRate – The baud rate of the port to be opened. (Check UART Ports Table)

config.flowControl – UART flow control can be set as TRUE or FALSE. TRUE value will enable flow control and FALSE value will disable flow control.

config.flowControlThreshold – Number of bytes left before Rx buffer reaches maxRxBufSize. When Rx buffer reaches this number (maxRxBufSize – flowControlThreshold) and flowControl is TRUE, a callback will be sent back to the application with HAL_UART_RX_ABOUT_FULL event.

config.idleTimeout – Rx timeout period in milliseconds. If Rx buffer haven't got new data for idleTimout amount of time, a callback will be issued to the application with HAL_UART_RX_TIMEOUT event. The application can choose to read everything from the Rx buffer or just partial of it.

 $\textbf{config.rx} - \textbf{Contains} \; \texttt{halUARTBufControl_t} \; \textbf{structure} \; \textbf{that} \; \textbf{used} \; \textbf{to} \; \textbf{manipulate} \; \textbf{Rx} \; \textbf{buffer}$

config.tx - Contains halUARTBufControl_t structure that used to manipulate Tx buffer

```
typedef struct
{
  uint16 bufferHead;
  uint16 bufferTail;
  uint16 maxBufSize;
  uint8 *pBuffer;
}halUARTBufControl_t;
```

bufferHead – contain the index of the starting position of the Rx/Tx buffer

bufferTail – contains the index of the ending position of the Rx/Tx buffer

maxBufSize – holds maximum size of the Rx/Tx buffer that the UART can hold at a time. When this number is reached, HAL_UART_RX_FULL or HAL_UART_TX_FULL will be sent back to the application as an event through the callback system.

*pBuffer – pointer to the buffer that contains the Rx data

config.intEnable – enable/disable interrupt. It can be set as TRUE or FALSE. TRUE value will enable the interrupt and FALSE value will disable the interrupt.

callBackFunc – This callback is called when there is an event such as Tx done, Rx ready...

```
void HalUARTCback (uint8 port, uint8 event);
```

port - specified serial port that has the event. (Check UART Ports Table).

event – event that causes the callback (<u>Check Events table</u>).

9.2.4 Return

Status of the function call. (Check Status Table).

9.3 HalUARTClose ()

9.3.1 Description

This function closes a given port. This allows settings to be reconfigured and opened again or power to be conserved by simply turn off the UART.

9.3.2 Prototype

```
void HalUARTClose (uint8 port);
```

9.3.3 Parameter Details

port - specified serial port to be closed. (Check UART Ports Table)

9.3.4 Return

None.

9.4 HalUARTRead ()

9.4.1 Description

This function reads a buffer from the UART. The buffer must be allocated by the application using OSAL osal_mem_alloc(). The buffer then will be de-allocated by the application using osal_mem_free(). The number of bytes to be read is determined by the application. If the requested length is larger than the Rx Buffer, then the requested length will be adjusted to the Rx buffer length and the whole Rx buffer is return together with the adjusted length. If the requested length is smaller than the Rx buffer length, then only requested length buffer is sent back. The Rx buffer will be updated after the requested buffer is sent back. The function returns the length of the data if it is successful and 0 otherwise.

9.4.2 Prototype

9.4.3 Parameter Details

port – specified serial port that data will be read. (Check UART Ports Table)

buf – pointer to the buffer of the data. This buffer must be allocated using osal_mem_alloc() in the application and must be de-allocated after being used by the application using osal_mem_free().

length – requested length.

9.4.4 Return

Returns the length of the read data or 0 otherwise.

9.5 HalUARTWrite ()

9.5.1 Description

This function writes a buffer of specific length into the serial port. The function will check if the Tx buffer is full or not. If the Tx Buffer is not full, the data will be loaded into the buffer and then will be sent to the Tx data register. If the Tx buffer is full, the function will send a callback HAL_UART_TX_FULL and return 0. Otherwise, the length of the data that was sent will be returned.

9.5.2 Prototype

9.5.3 Parameter Details

```
port – specified serial port that data will be read. (<u>Check UART Ports Table</u>)
```

buf – buffer of the data.

length- the length of the data

9.5.4 Return

Returns the length of the data that is successfully written or 0 otherwise.

9.6 HalUARTIoctl ()

9.6.1 Description

This function is used to perform operations on the port such as get/set, flush...etc

9.6.2 Prototype

9.6.3 Parameter Details

```
port – specified serial port that data will be read. (Check UART Ports Table)
```

cmd – operational commands

| Command | Description |
|----------------------|---------------------------------------------------------------------|
| HAL_UART_IOCTL_SET | SET operation – use this to set the new setting for the UART |
| HAL_UART_IOCTL_GET | GET operation – use this to get the current setting of the UART |
| HAL_UART_IOCTL_FLUSH | FLUSH operation – use this to reset the current setting of the UART |

ioctl – union of parameters associated with the commands

```
typedef union
{
    bool paramCTS;
    bool paramDSR;
    bool paramDTR;
    bool paramDTR;
    bool paramCD;
    bool paramRI;
    uint16 baudRate;
    bool flowControl;
    bool flushControl;
}
```

signals – new setting for CTS, RTS, DSR, DTR, CD and RI.

baudRate – the new value of the baud rate for the given port. (Check Baud Rate Table)

flowControl – UART flow control, can be set as TRUE or FALSE. TRUE value will enable flow control and FALSE value will disable flow control.

flushControl – UART flush control, can be set as TRUE or FALSE. TRUE value will stop all the operation and flush all the data.

9.6.4 Return

Status of the function call. (Check Status Table).

9.7 HalUARTPoll()

9.7.1 Description

This routine simulates the polling mechanism for UART.

9.7.2 Prototype

```
void HalUARTPoll (void);
```

9.7.3 Parameter Details

None.

9.7.4 Return

None.

9.8 Hal_UART_RxBuffLen()

9.8.1 Description

This function returns the number of bytes currently in the Rx buffer.

9.8.2 Prototype

```
uint16 Hal_UART_RxBufLen (uint8 port);
```

9.8.3 Parameter Details

port – specified serial port that length will be read. (Check UART Ports Table)

9.8.4 Return

16 bit size of the Rx buffer.

9.9 Hal_UART_TxBuffLen()

This function returns the number of bytes currently in the Tx buffer.

9.9.1 Description

This function returns the number of bytes currently in the Rx buffer.

9.9.2 Prototype

```
uint16 Hal_UART_TxBufLen (uint8 port);
```

9.9.3 Parameter Details

port – specified serial port that length will be read. (Check UART Ports Table)

9.9.4 Return

16 bit size of the Tx buffer.

9.10 Hal_UART_FlowControlSet()

9.10.1 Description

This function enables or disables the flow control for the UART.

9.10.2 Prototype

9.10.3 Parameter Details

```
port – specified serial port that flow control will be set. (<u>Check UART Ports Table</u>)
```

status - TRUE or FALSE, enable or disable the flow control

9.10.4 Return

None.

9.11 Constants

9.11.1 UART Ports

| Port | Description |
|-----------------|-------------|
| HAL_UART_PORT_1 | UART port 1 |
| HAL_UART_PORT_2 | UART port 2 |

9.11.2 Baud Rates

| Parameter | Desription |
|--------------------|----------------------|
| HAL_UART_BR_1200 | Baud rate 1200 bps |
| HAL_UART_BR_2400 | Baud rate 2400 bps |
| HAL_UART_BR_4800 | Baud rate 4800 bps |
| HAL_UART_BR_9600 | Baud rate 9600 bps |
| HAL_UART_BR_19200 | Baud rate 19200 bps |
| HAL_UART_BR_31250 | Baud rate 31250 bps |
| HAL_UART_BR_38400 | Baud rate 38400 bps |
| HAL UART BR 57600 | Baud rate 57600 bps |
| HAL_UART_BR_115200 | Baud rate 115200 bps |

9.11.3 Parity

| Parameter | Desription |
|----------------------|-------------|
| HAL_UART_NO_PARITY | No parity |
| HAL_UART_ODD_PARITY | Odd parity |
| HAL_UART_EVEN_PARITY | Even parity |

9.11.4 Stop Bits

| Parameter | Desription |
|------------------------|-------------|
| HAL_UART_ONE_STOP_BIT | Stop Bits 1 |
| HAL_UART_TWO_STOP_BITS | Stop Bits 2 |

9.11.5 Status

| Parameter | Desription |
|--------------------|-------------------------|
| HAL_UART_SUCCESS | Success |
| HAL_UART_MEM_FAIL | Fail to allocate memory |
| HAL_UART_BAUDRATE_ | Baud rate is bad |

9.11.6 Callback Events

| Event | Desription |
|------------------------|-----------------------------------------------------|
| HAL_UART_RX_FULL | Rx Buffer is full |
| HAL_UART_RX_ABOUT_FULL | Rx Buffer is at maxRxBufSize - flowControlThreshold |
| HAL_UART_RX_TIMEOUT | Rx is idle for idleTimout time |
| HAL_UART_TX_FULL | Tx Buffer is full |