mioty® Gateway AVA

QUICK 4-STEP GUIDE

ENGLISH

1 **DEVICE INSTALLATION**
Connect the AVA gateway to LAN with DHCP support.

2 **ANTENNA CONNECTION**
Attach antenna to AVA gateway.

3 **CONNECTION**
Plugin USB-C Raspberry PI power supply.

4 **GET STARTED**
Open your web browser and type in „ava/“. You will get to the dashboard of the gateway.

NOTE: An internet connection is required to use the gateway. Eventually you must consult your IT department to grant the gateway access to the internet.

mioty® Gateway AVA

QUICK 4-STEP GUIDE

DEUTSCH

1

INBETRIEBNAHME
Verbinden Sie das AVA Gateway mit LAN, inklusive DHCP Unterstützung.

2

ANTENNENVERBINDUNG
Verbinden Sie die Antenne mit dem AVA Gateway.

3

VERBINDEN
Schließen Sie das USB-C Raspberry Pi Netzteil an.

4

LEGEN SIE LOS
Öffnen Sie ihren Web Browser und geben „ava/“ ein. So gelangen ins Dashboard des Gateways.

HINWEIS: Für die Benutzung des Gateways ist ein Internetverbindung notwendig. Ggf. müssen Sie Rücksprache mit Ihrer IT-Abteilung halten, um dem Gateway den Zugriff auf das Internet zu erlauben.

mioty® Gateway AVA

QUICK 4-STEP GUIDE

mioty® Gateway AVA

QUICK 4-STEP GUIDE

4



ENGLISH

The Gateway can be connected to your local network via Ethernet. It offers a web interface that gives overview and insights into all available mioty® traffic. It also contains rudimentary development implementations for mioty® application and service centers that allow you to configure your development sensors, decode their traffic, and forward their data via MQTT for easy evaluation. It is also possible to configure the gateway to connect to Application and Service Centers of your choice via BSSCI instead.

DEUTSCH

Das Gateway kann über Ethernet mit Ihrem lokalen Netzwerk verbunden werden. Es bietet eine Weboberfläche, die einen Überblick und Einblicke in den gesamten verfügbaren mioty® -Verkehr bietet. Es enthält auch rudimentäre Entwicklungsimplementierungen für mioty® Application und Service Center, mit denen Sie Ihre Entwicklungssensoren konfigurieren, ihren Datenverkehr dekodieren und ihre Daten zur einfachen Auswertung über MQTT weiterleiten können. Es ist auch möglich, das Gateway so zu konfigurieren, dass stattdessen über BSSCI eine Verbindung zu Anwendungs- und Servicecentern Ihrer Wahl hergestellt wird.

mioty® Gateway AVA

QUICK 4-STEP GUIDE

4



ENGLISH

In order to **forward your data via MQTT**, the orange highlighted field in the illustration above must be completed.

In order to **add our mioty® sensors**, the blue highlighted field in the illustration above must be completed as follows:

- EUI (extended unique identifier)
- ShAddr = d000
- PreAtt = Haken gesetzt
- Network Key
- Application Key (optional)

Expert Settings: to make further changes you can login via SSH (username: ubuntu, password: ubuntu)

DEUTSCH

Um die **Daten über MQTT weiterzuleiten**, müssen die in der Darstellung orange hervorgehobenen Felder wie folgt ausgefüllt werden:

Um **unsere mioty® Sensoren hinzuzufügen**, müssen die folgenden Felder im blau hervorgehobenen Bereich in der Darstellung ausgefüllt werden.

- EUI (extended unique identifier)
- ShAddr = d000
- PreAtt = box checked
- Network Key
- Application Key (optional)

Expert Settings: es können weitere Änderungen über SSH vorgenommen werden (username: ubuntu Passwort: ubuntu)