

## **Altium Designer - Basic Keyboard Shortcuts**

## Schematic Design

Command Description	Keyboard Shortcut
Place Component	Р
Zoom	Z
Align	A
Undo	Ctrl-Z
Rotate Part or Symbol	Space Bar (on drag or select)
Mouse Zoom	Ctrl + Scroll Wheel
Properties Dialog Box (in context)	TAB
Place Wire	P -> W
Place Bus	P -> B
Place Power	P -> O
Drag Part with Existing Wiring	Ctrl + Mouse Drag
Select Multiple Objects	Shift + Mouse Click

## PCB Design

Command Description	Keyboard Shortcut
Place Via	2
Toggle Standard track sizes	3
Zoom	Ctrl + Scroll Wheel
Place Menu	Р
Zoom Menu	Z
Selection Menu	S
Properties Dialog Box (in context)	TAB
Place Interactively Routed Track	P -> T
Undo Last Routing Point	BACKSPACE
Layer Manager	L
Design Menu	D
Multiple Select	Shift + Left Click
Quick Dimension Change (mil or mm)	q
Quick Layer Change [numpad]	+ / -
Quick Layer Change [mouse]	CTRL + SHIFT + Scroll Wheel
Single Layer Mode	SHIFT + S
Clear Current Tool	ESC
Change Track Direction	SPACE
Change Track Routing Style	SHIFT + SPACE