XENTRINOBOT MANUAL 1.0

Hi-Techno Barrio



Christopher M Coballes BSCoE, BSECE, BSEE, MIS

TABLE OF CONTENTS

Part I

Assembly Guide

Parts & materials
2WD mobile robots
4WD mobile robots
1-3 decks
Nuts & bolts
Motor and wheels
Positioning Lidar

Electronics Guide

Battery
Board
Driver modules
Circuit Connections of motors
Check polarity of IMU
Connect Lidar

Single Board Computer Guide

OS image downloading (Ubuntu Mate) Software imager downloading SD Card imaging Running the OS for the first time in SBC Libraries and driver installations

Installing ROS

Downloading from the github
Install software or libraries to setup ROS
Install the ROS package
Create workspace
Download xentrinobot ROS package in the workspace
Compile the ROS package

Installing XentrinoBot

Downloading firmware from the github Installing libraries and main source code Installing firmware using platform.io Installing firmware using Arduino IDE

Configuration of Xentrinobot

Modify the xentrinobot_base_config.h Set mobile robotics wheels platform Set the controller and drivers

Communicate ROS and Xentrinobot

Testing motors, imu and encoders Tuning PID Calibrating IMU Checking Lidars

PART II

Getting started w/ ROS

Xentrinobot Base Controller

Odometry

Laser Sensor

Transformation

Creating a Map

Autonomous Navigation

Part III

Designing Robot
Understanding the firmware
Understanding the ROS source code and libraries
Setup Xentrinobot into different mobile robotics configurations.

Part IV

Xentrinobot applications
Line following xentrinobot
Web controlled xentrinobot
Using OpenCV for road and lane detection
Adding different sensors

Part V

Al Symbolic using Xentrinobot Machine Learning using Xentrinobot Deep Learning using Xentrinobot