# Special Topics on Basic EECS I VLSI Devices Lecture 20

Sung-Min Hong (<a href="mailto:smhong@gist.ac.kr">smhong@gist.ac.kr</a>)
Semiconductor Device Simulation Laboratory
School of Electrical Engineering and Computer Science
Gwangju Institute of Science and Technology

# Surface potential, $\phi_s \equiv \phi(0) - \phi(\infty)$

- A downward bending of bands in the p-type silicon near the surface
  - It is important to note that

$$V_g - V_{fb} = \phi_s + V_{ox}$$

At the silicon-oxide interface,

$$\epsilon_{ox}|\mathbf{E}_{ox}| = \epsilon_{si}|\mathbf{E}_{si}|$$


-Since 
$$\epsilon_{ox} = 3.9\epsilon_0$$
 and  $\epsilon_{si} = 11.7\epsilon_0$ ,  $|\mathbf{E}_{ox}| \approx 3|\mathbf{E}_{si}|$ 

Taur, Eq. (2.172)


Taur, Eq. (2.173)

#### **TCAD** simulation

- Model parameter
  - -Workfunction of 4.17 eV
  - -Oxide thickness of 20 Å
  - -P-type doping of 1X10<sup>18</sup> cm<sup>-3</sup>




- $V_g$  = -2.0 V -Accumulation
- Hole density




•  $V_g = -0.94 \text{ V}$ 


Flatband condition



- $V_g$  = 0.0 V - Depletion
- Space charge




- $V_g = 1.0 \text{ V}$ -Inversion
- Electron density




#### Threshold voltage (1)

Draw quantities as functions of the gate voltage.



# **Threshold voltage (2)**

• The same graph, in the linear scale,



# **Depletion approximation**

- Electric field (V/cm) Position (µm)  $W_d$
- Consider a depleted MOS structure.
  - With the depletion width,  $W_d$ ,

$$\phi_{s} = \frac{1}{2} W_{d} \left( q \frac{N_{a}}{\epsilon_{si}} W_{d} \right)$$

-Then,

$$W_d = \sqrt{\frac{2\epsilon_{si}\phi_s}{qN_a}}$$

0 (No field)

Oxide

P-type substrate

-Total depletion charge in silicon,  $Q_d$ , is

$$Q_d = -qN_aW_d = -\sqrt{2\epsilon_{si}qN_a\phi_s}$$

Taur, Eq. (2.188)

Taur, Eq. (2.189)


# **Potential profile**

- A parabolic potential profile
  - -The depletion region cannot grow indefinitely.

-When  $\phi_S = 2\phi_B$ ,  $n(0) = p(\infty)$ 

The surface behaves liken-type material. (Inversion)


 $-\phi_s$  is approximately pinned.



#### Maximum depletion width

• Therefore, maximum depletion width becomes

$$W_d = \sqrt{\frac{4\epsilon_{si}\phi_B}{qN_a}} = \sqrt{\frac{4\epsilon_{si}k_BT \ln(N_a/n_i)}{q^2N_a}}$$
 Taur, Eq. (2.190)



← Depletion charge does not increase.

Gate voltage (V)

#### Beyond threshold voltage

It's not perfectly fixed.

- The surface potential is <u>almost</u> fixed. (Surface potential pinning)
  - –Small additional change in  $\phi_{\scriptscriptstyle S}$  induces an exponential increase of the electron density.
  - Remember that  $n = n_i \exp\left(\frac{q\phi}{k_B T}\right)$ .
  - When  $\phi_S=2\phi_B$ ,

$$n(0) = n_i \exp\left(\frac{q\phi_B}{k_B T}\right) = p(\infty)$$

–Additional potential ( $\Delta\phi$ ) yields

$$n(0) = p(\infty) \exp\left(\frac{q\Delta\phi}{k_B T}\right)$$

It's a high density.

# General relation beyond depletion approx. (1)

With the depletion approximation, we obtained

$$Q_d = -qN_aW_d = -\sqrt{2\epsilon_{si}qN_a\phi_s}$$

- We can do much better!
  - -A generation relation for  $Q_s = Q_d + Q_i$
  - The Poisson equation

$$\frac{d^2\phi}{dx^2} = -\frac{q}{\epsilon_{si}}[p(x) - n(x) - N_a]$$

Inversion charge

Taur, Eq. (2.175)

#### General relation beyond depletion approx. (2)

Following Taur's notation,

For a while,  $\phi(\infty) = -\phi_B$  is used as the reference value. Therefore,

$$n(x) = n_i \exp\left(\frac{q\phi(x)}{k_BT}\right) \rightarrow n(x) = n(\infty) \exp\left(\frac{q\phi(x)}{k_BT}\right)$$
 Taur, Eq. (2.178)  
 $p(x) = n_i \exp\left(-\frac{q\phi(x)}{k_BT}\right) \rightarrow p(x) = p(\infty) \exp\left(-\frac{q\phi(x)}{k_BT}\right)$  Taur, Eq. (2.177)

Taur, Eq. (2.178)

-The Poisson equation

$$\frac{d^2\phi}{dx^2} = -\frac{q}{\epsilon_{si}} \left[ N_a \left( \exp\left(-\frac{q\phi}{k_B T}\right) - 1 \right) - \frac{n_i^2}{N_a} \left( \exp\left(\frac{q\phi}{k_B T}\right) - 1 \right) \right]$$

Taur, Eq. (2.179)

#### General relation beyond depletion approx. (3)

- Multiplying  $\frac{d\phi}{dx} dx$ ,
  - -The Poisson equation

$$\frac{d\phi}{dx}d\left(\frac{d\phi}{dx}\right) = -\frac{q}{\epsilon_{si}}\left[N_a\left(\exp\left(-\frac{q\phi}{k_BT}\right) - 1\right) - \frac{n_i^2}{N_a}\left(\exp\left(\frac{q\phi}{k_BT}\right) - 1\right)\right]d\phi$$

- Integrate the above equation.

Integrate the above equation. 
$$\int_{0}^{-E_{x}(x)} \frac{d\phi}{dx} d\left(\frac{d\phi}{dx}\right)$$
 Taur, Eq. (2.180) 
$$= -\frac{q}{\epsilon_{si}} \int_{0}^{\phi(x)} \left[ N_{a} \left( \exp\left(-\frac{q\phi}{k_{B}T}\right) - 1 \right) - \frac{n_{i}^{2}}{N_{a}} \left( \exp\left(\frac{q\phi}{k_{B}T}\right) - 1 \right) \right] d\phi$$

# General relation beyond depletion approx. (4)

• (Square of) Electric field

-From 
$$\frac{1}{2}E_{\chi}^{2}(x) = -\frac{q}{\epsilon_{si}}\left[-N_{a}\frac{k_{B}T}{q}\exp\left(-\frac{q\phi}{k_{B}T}\right) - N_{a}\phi + N_{a}\frac{k_{B}T}{q} - \frac{n_{i}^{2}}{N_{a}}\frac{k_{B}T}{q}\exp\left(\frac{q\phi}{k_{B}T}\right) + \frac{n_{i}^{2}}{N_{a}}\phi + \frac{n_{i}^{2}}{N_{a}}\frac{k_{B}T}{q}\right]$$
, we get

$$\begin{aligned} &E_{\chi}^{2}(\chi) \\ &= \frac{2k_{B}TN_{a}}{\epsilon_{si}} \left[ \left( \exp\left(-\frac{q\phi}{k_{B}T}\right) + \frac{q\phi}{k_{B}T} - 1 \right) \right. \\ &\left. + \frac{n_{i}^{2}}{N_{a}^{2}} \left( \exp\left(\frac{q\phi}{k_{B}T}\right) - \frac{q\phi}{k_{B}T} - 1 \right) \right] \end{aligned}$$

Taur, Eq. (2.181)

#### General relation beyond depletion approx. (5)

- At x=0, we have  $\phi(0)=\phi_{\mathcal{S}}$ .
  - -Then,

$$\begin{aligned} &E_s^2 \\ &= \frac{2k_BTN_a}{\epsilon_{si}} \left[ \left( \exp\left( -\frac{q\phi_s}{k_BT} \right) + \frac{q\phi_s}{k_BT} - 1 \right) \right. \\ &+ \frac{n_i^2}{N_a^2} \left( \exp\left( \frac{q\phi_s}{k_BT} \right) - \frac{q\phi_s}{k_BT} - 1 \right) \right] \end{aligned}$$

# General relation beyond depletion approx. (6)

$$\begin{split} \bullet & \text{ At } x=0 \text{, we have } \phi(0)=\phi_{S}. \\ & -\text{From } Q_{S}=-\epsilon_{si}E_{S}, \\ & Q_{S} \\ & =\pm\sqrt{2\epsilon_{si}k_{B}TN_{a}}\left[\left(\exp\left(-\frac{q\phi_{S}}{k_{B}T}\right)+\frac{q\phi_{S}}{k_{B}T}-1\right)\right. \\ & \left.+\frac{n_{i}^{2}}{N_{a}^{2}}\left(\exp\left(\frac{q\phi_{S}}{k_{B}T}\right)-\frac{q\phi_{S}}{k_{B}T}-1\right)\right]^{1/2} \end{split}$$
 Taur, Eq. (2.182)

#### Homework#4

- Draw  $|Q_S|$  as a function of  $\phi_S$ .
  - -Assume that  $N_a$  is  $4 \times 10^{15}$  cm<sup>-3</sup>.
  - $-\phi_{\scriptscriptstyle S}$  varies from -0.4 V to 1.0 V.

# Thank you!