VLSI Devices Lecture 3


Sung-Min Hong (smhong@gist.ac.kr)
Semiconductor Device Simulation Laboratory
Department of Electrical Engineering and Computer Science
Gwangju Institute of Science and Technology (GIST)

Drift

- Net movement of charge due to an electric field
 - Since electrons/holes are charged particles, they are accelerated by an electric field. (V/cm)
 - -For electrons, $\mathbf{F} = -q\mathbf{E}$ (For holes, $\mathbf{F} = +q\mathbf{E}$.)
 - According to Newton's 2nd law, the velocity satisfies $\frac{d\mathbf{v}}{dt} = -\frac{q\mathbf{E}}{m_n}$
 - Here, m_n is the conductivity effective mass of electrons.
 - -Then, $\mathbf{v}(t) = \mathbf{v}(0) \frac{q\mathbf{E}}{m_n}t$ (Right?)

Scattering

- The velocity of the carriers...
 - Does not increase indefinitely under the field acceleration. Why?
 - -They are scattered frequently and lose the momentum.



Velocity of an electron as a function of time, when scattering events are considered.

Average velocity

- The velocity of each carrier
 - An indivisual electron exhibits sharp transitions.
- The average velocity
 - However, the average velocity follows a much smoother trajectory.
 - -Therefore, it would be better to write

$$\frac{d\langle \mathbf{v} \rangle}{dt} = -\frac{q\mathbf{E}}{m_n} - \frac{\langle \mathbf{v} \rangle}{\tau_n}$$

– Here, τ_n is the mean time between collisions.

Mobility

	μ_n	μ_p
Si	1350	480
GaAs	8500	400
Ge	3900	1900

Mobility

- Conduction currents are the result of the drift motion of charge carriers under the influence of an applied electric field.
- Average drift velocity is directly proportional to the electric field intensity:

$$\langle \mathbf{v} \rangle = -\frac{q\tau_n}{m_n} \mathbf{E} = -\mu_n \mathbf{E}$$

Taur, Eq. (2.26)

 $-\mu_n$: Electron mobility in (cm² V⁻¹ sec⁻¹)

Negative sign due to polarity

- When the above relation is used, the drift current density becomes


$$\mathbf{J} = q(\mu_n n + \mu_p p)\mathbf{E} = \sigma \mathbf{E}$$

Taur, Eq. (2.28)

and Eq. (2.30)

Terminal current vs. current density

• J, current per area (defined everywhere)



Current density vector (Luisier et al., JAP, vol. 100, p. 043713, 2006)

Surface integral of a vector field (Wikipedia)

Resistivity & sheet resistivity

Drift current density

$$\mathbf{J}_{n,drift} = q\mu_n n\mathbf{E}$$
 Taur, Eq. (2.28)
$$\mathbf{J}_{p,drift} = q\mu_p p\mathbf{E}$$
 Taur, Eq. (2.30)
$$-\text{Then, the total resistivity is}$$

$$\Omega \text{ cm} \longrightarrow \rho = \frac{1}{q\mu_n n + q\mu_p p}$$
 Taur, Eq. (2.32)

Sheet resistivity


 Ω cm

-The resistance of a conductor of length, L, and width, W,

$$R = \frac{L}{W} \rho_{sh}$$
 Taur, Eq. (2.35)

Phonon scattering

- Various phonon modes
 - Acoustic phonon : Low energy
 - Optical phonon : High energy, often treated as dispersion-less




"Selection rule" matters. Intravalley / f-process / gprocess

Typical parameters

- Various phonon modes
 - Acoustic phonon : Low energy


Mode	$D_t K (10^8 \text{eV/cm})$	ħω (meV)	Туре
TA	0.470	12.1	g-type
LA	0.740	18.5	g-type
LO	10.23	62.0	g-type
TA	0.280	19.0	f-type
LA	1.860	47.4	f-type
LO	1.860	58.6	f-type

Parameters for inelastic phonon scatterings in the Si conduction band




Temperature & doping

(Neamen's book)



Impurity concentration

It is modeled as an elastic scattering process.



(Neamen's book)

• Which one is dominant? Phonon or impurity?

– Matthiessen's rule,
$$\frac{1}{\mu} = \frac{1}{\mu_I} + \frac{1}{\mu_L}$$

Taur, Eq. (2.27)

Matthiessen's rule


- When there are multiple contributions to the mobility,
 - (For example, phonon-limited mobility / impurity-limited mobility)
 - The overall collision rate is given by sum of all contributions.

$$-\frac{1}{\tau_m} = \frac{1}{\tau_{mL}} + \frac{1}{\tau_{mI}} + \cdots$$

- (The above relation holds exactly only in the microscopic level.)
- When recalling $\mu=\frac{q\tau_m}{m_n}$, it means $\frac{1}{\mu_m}=\frac{1}{\mu_{mL}}+\frac{1}{\mu_{mI}}+\cdots$
- It is very useful.

Hot electron

- Not only velocity, but also energy...
 - Increases when the electric field increases.
 - Increase of energy is a reason of the velocity saturation. Why?




Up to 1 kV/cm, average energy is almost the same with the lattice energy.

Above 10 kV/cm, average energy significantly deviates from the lattice energy.

Average energy of electrons/holes in Si at 300K (Park's book)

Velocity saturation

- Electron with higher energy
 - Has a higher chance to be scattered by phonons. (Higher DOS)
 - More frequent scattering : Smaller au_m




Phonon scattering rate in Si resembles the Density-Of-States.

Phonon scattering rate in Si (Jungemann's book)

Velocity vs. electric field

- At low electric fields, the linear relationship is valid.
 - At high electric fields, the velocity saturation starts to occur. The saturation velocity of Si is about 10⁷ (cm/sec).



Velocity-field relationship in Si at 300K (Taur's book)

Caughey-Thomas relation

- For silicon,
 - Electron velocity can be approximated by

$$v_n = \frac{v_s}{\left[1 + \left(\frac{E_{on}}{E}\right)^2\right]^{0.5}}$$


Hole velocity

$$v_p = \frac{v_s}{\left[1 + \left(\frac{E_{op}}{E}\right)\right]}$$

– Why are they different?

Other scattering mechanisms

- We have discussed about the bulk mobility.
 - Other scattering mechanisms (alloy scattering & impact ionization)
 - Surface scattering severely reduces the inversion mobility.




So-called "universal" mobility curve in the Si inversion layer.

Two difference contributions are clearly visible.

Electron mobility versus effective field for several doping concentrations (Takagi's paper)

Diffusion

- It is not only for charged particles.
 - For example,



Diffusion of ink (Google images)

-Therefore, no polarity is expected.

Equation

- Flux
 - -The electron flux due to the diffusion mechanism is given by

$$\mathbf{F}_n = -D_n \nabla n$$

where D_n is the electron diffusion coefficient in the unit of (cm²/sec).

-The diffusion current density is

$$\mathbf{J}_{n,diff} = q D_n \nabla n$$

Taur, Eq. (2.36)

- How about the hole?
 - The diffusion current density is

$$\mathbf{J}_{p,diff} = -qD_p \nabla p$$

Taur, Eq. (2.37)

Revisit the total current density.

- Total current density
 - Electron current density

$$\mathbf{J}_n = q\mu_n n\mathbf{E} + qD_n \nabla n$$

Hole current density

$$\mathbf{J}_p = q\mu_p p \mathbf{E} - q D_p \nabla p$$

- (Time-dependent) displacement current density

$$\mathbf{J}_{displacement} = \frac{\partial}{\partial t} (\epsilon \mathbf{E})$$

Taur, Eq. (2.54)


Taur, Eq. (2.55)

Einstein relation

• At equilibrium, we have the following relations:

$$D_n = \frac{k_B T}{q} \mu_n$$
, $D_p = \frac{\bar{k}_B T}{q} \mu_p$

Taur, Eq. (2.38) and Eq. (2.39)



(Park's book)

Current density with Einstein relation

- Alternative forms
 - Electron current density

$$\mathbf{J}_n = -q\mu_n n \left[\nabla \phi - \frac{k_B T}{q} \frac{1}{n} \nabla n \right]$$

Taur, Eq. (2.56)

Hole current density

$$\mathbf{J}_{p} = -q\mu_{p}p\left[\nabla\phi + \frac{k_{B}T}{q}\frac{1}{p}\nabla p\right]$$

Taur, Eq. (2.57)

Revisiting carrier concentrations

 $E_f = -q\phi_f$

Carrier densities are expressed as

$$n = n_i \exp\left(-\frac{E_i - E_f}{k_B T}\right) = n_i \exp\left(\frac{\phi - \phi_f}{k_B T/q}\right)$$
 Taur, Eq. (2.49)

$$p = n_i \exp\left(\frac{E_i - E_f}{k_B T}\right) = n_i \exp\left(-\frac{\phi - \phi_f}{k_B T/q}\right)$$
 Taur, Eq. (2.50)

 These relations are generally applicable in the presence of net charge and band bending.

Extension to non-equilibrium cases

- ullet Of course, at non-equilibrium cases, we cannot define E_f .
 - However, we introduce ϕ_n and ϕ_p to satisfy:

$$n = n_i \exp\left(\frac{\phi - \phi_n}{k_B T/q}\right)$$
 Taur, Eq. (2.61)

$$p = n_i \exp\left(-\frac{\phi - \phi_p}{k_B T/q}\right)$$
 Taur, Eq. (2.62)

 They are called quasi-Fermi potentials. (Electron quasi-Fermi potential and hole quasi-Fermi potential)

Current density with $abla\phi_n$ and $abla\phi_p$

- From the expression for the quasi-Fermi potential,
 - It can be written as

$$\phi_n = \phi - \frac{k_B T}{q} \log \frac{n}{n_i}$$

Taur, Eq. (2.65)

- Taking the gradient,

$$\nabla \phi_n = \nabla \phi - \frac{k_B T}{q} \frac{\nabla n}{n}$$

-Using this expression,

$$\mathbf{J}_n = -q\mu_n n \left[\nabla \phi - \frac{k_B T}{q} \frac{1}{n} \nabla n \right] = -q\mu_n n \nabla \phi_n \text{ Taur, Eq. (2.63)}$$

$$\mathbf{J}_p = -q \mu_p p
abla \phi_p$$

Taur, Eq. (2.64)

Gradient of quasi-Fermi potential

We have the following relations,

$$\mathbf{J}_n = -q\mu_n n \nabla \phi_n$$

$$\mathbf{J}_p = -q\mu_p p \nabla \phi_p$$

- The gradient of electron quasi-Fermi potential drives the electron current.
- The gradient of hole quasi-Fermi potential drives the hole current.

Boundary conditions for ϕ_n and ϕ_p


- Dirichlet boundary condition
 - At terminals,

$$\phi_n = \phi_p = V_{app}$$

Neumann boundary condition

No current through non-contact surfaces

$$\nabla \phi_n \cdot \mathbf{n} = \nabla \phi_p \cdot \mathbf{n} = 0$$



Thank you!