





Sede Amm.va/Show-Room/Dep.; Via G. Galilei. 9-11 · 31021 MOGLIANO V.TO · TV · ITALY



English

ASSEMBLY INSTRUCTION

Check there is no network voltage before installing the equipment.

- Loosen the set screw (3), loosen the screws (1) blocked by the toothed washers (2), and then free the frame (4) from the fastening bracket (5).
- Fasten the wall bracket (5) using the screws (6) and dowels (7), passing the power cables (8) through the central hole.
- Make the connection starting from the yellow / green earth cable which should be fixed to the central terminal of the terminal box (9), then connect the remaining two wires L and N to the side terminals.
- Take the components of packaged separately mount, and unscrew completely. Insert the threaded rod (13) in the frame (4) and fasten to it through nut (11) and serrated washer (10) as from illustration. By means of the screwing of the threaded rod (13) is possible adjust the height depending on the thickness of glass (15).
- Screw the upper ring nut (14a), up to contact with the frame (4), then insert the tube (12) and secure with lower ring (14b).
- Close the frame (4) and secure it with the grain (3) previously unscrewed.
- Tighten bulbs (17) in the holder (18).
- Place the first sheath (16a) in contact with the lower ring (14b) and insert the glass (15).
- Lock it with the second sheath (16b), the component (19) and the glides (20) as illustrated.

Italiano

ISTRUZIONI DI MONTAGGIO

Sede Legale: Fondamenta Radi, 25/B – 30121 MURANO Cap. Soc. = 100.000,00 I.V. – P.IVA IT02497840278 • COD. |

Assicurarsi che non sia presente tensione di rete prima di procedere all'installazione dell'apparecchio.

- Allentare il grano (3), svitare le viti (1) bloccate dalle rondelle dentellate (2) e quindi liberare la montatura (4) dalla staffa di fissaggio (5).
- Fissare a parete la staffa di fissaggio (5) tramite le apposite viti (6) e tasselli (7), passando i cavi di alimentazione (8) attraverso il foro centrale.
- Eseguire il collegamento iniziando dal cavo giallo/verde di terra che dovrà essere fissato al morsetto centrale della morsetteria (9), quindi collegare i rimanenti due cavi L e N ai morsetti laterali.
- Prendere i componenti della montatura imballati a parte, e svitarli completamente. Inserire la canna filettata (13) nella montatura (4) e fissarla ad essa tramite dado (11) e rondella dentellata (10) come da illustrazione. Mediante l'avvitamento della canna filettata (13) è possibile regolarne l'altezza a seconda dello spessore del vetro (15).
- Awitare la ghiera superiore (14a), fino a contatto con la montatura (4), successivamente inserire tubo (12) e bloccare con ghiera inferiore (14b).
- Richiudere la montatura (4) e fissarla col grano (3) precedentemente svitato.
- Avvitare le lampadine (17) nei portalampade (18).
- Porre la prima guaina (16a) a contatto con la ghiera inferiore (14b) e inserire il vetro(15).
- Bloccarlo con la seconda guaina (16b), il componente (19) e il finalino (20) come da illustrazione.

VETRERIA VISTOSI Srl · Via G. Galilei, 9-11 31021 Mogliano Veneto · Treviso · Italy Tel. +39 041 5903480 · Fax +39 041 5900992 www.vistosi.it · vistosi@vistosi.it

