

No	Control Elements	No	Control Elements	No	Adjustments UP
A	Solenoid 'Up Stop'	V	Check Valve	1	By Pass
C	Solenoid 'Down Dec.'	X	Down Valve	5	Up Soft Stop
D	Solenoid 'Down Stop'	Y	Down Level Valve	No	Adjustments DOWN
U	Bypass Valve	F	Main Filter	6	Down Acceleration
H	Manuel Lowering	S	Relief Valve	7	Down Full Speed
M1	Test Port			9	Down Levelling Speed

