




No	Control Elements	No	Control Elements	No	Adjustments UP	No	Adjustments DOWN
A	Solenoid 'Up Stop'	U	By Pass Valve	1	By Pass	6	Down Acceleration
B	Solenoid 'Up Dec.'	V	Check Valve	2	Up Acceleration	7	Down Full Speed
C	Solenoid 'Down Dec.'	W	Levelling Valve Up	3	Up Deceleration	8	Down Deceleration
D	Solenoid 'Down Stop'	X	Full Speed Valve Down	4	Up Levelling Speed	9	Down Levelling Speed
H	Manuel Lowering	Y	Levelling Valve Down	5	Up Stop		
M1	Test Port	F	Filter				
S	Relief Valve						

#	Description / Açıklama	Marka / Brand	Kod / Code	Ad/Q
10	Oil Tank	-	-	1
11	Filter	-	-	1
12	Pump	-	-	1
13	Motor	-	-	1
14	Pressure Switch	-	-	1
15	Hose Burst Valve	-	-	1
16	Cylinder	-	-	1

#	Description / Açıklama	Marka / Brand	Kod / Code	Ad/Q
21	Filter	-	-	1
22	Pump	-	-	1
23	Motor	-	-	1
24	Relief Valve	-	-	1
25	Check Valve	-	-	1
26	NG6 Valve (OC)	-	-	1
27	Lock Cylinder	-	-	4
28	Cool Pump	-	-	1
29	Check Valve 8 Bar	-	-	1
30	Cooling Motor	-	-	1



KOD HS-HP 1331	Seri No / Serial No
TARİH 28.08.2025	REVİZYON 1

HİDROLİK ŞEMA HYDRAULIC SCHEMA

Model
DHYA

ÖNDER LİFT