



| No | Control Elements | No | Control Elements | No | Adjustments UP |
|----|----------------------|----|------------------|----|----------------------|
| A | Solenoid 'Up Stop' | V | Check Valve | 1 | By Pass |
| C | Solenoid 'Down Dec.' | X | Down Valve | 5 | Up Soft Stop |
| D | Solenoid 'Down Stop' | Y | Down Level Valve | No | Adjustments DOWN |
| U | Bypass Valve | F | Main Filter | 6 | Down Acceleration |
| H | Manuel Lowering | S | Relief Valve | 7 | Down Full Speed |
| M1 | Test Port | | | 9 | Down Levelling Speed |

| # | Description | Marka / Brand | Kod / Code | Ad/Q |
|----|------------------|---------------|------------|------|
| 10 | Oil Tank | - | - | 1 |
| 11 | Filter | - | - | 1 |
| 12 | Pump | - | - | 1 |
| 13 | Motor | - | - | 1 |
| 14 | Pressure Switch | - | - | 1 |
| 15 | Hose Burst Valve | - | - | 4 |
| 16 | Cylinder | - | - | 4 |



KOD
HS-HP 1214
TARİH
28.08.2025

Seri No / Serial No
REVİZYON
1

HİDROLİK ŞEMA HYDRAULIC SCHEMA

Model
DHYA

ÖNDER LİFT