

```
Single stack frame

int add10(int a, int b)
{
  return a + b;
}
```

The stack is a block of memory reserved for a program. Stacks usually go down -- the start of the stack is its highest address. As the program executes, the stack grows down as more space is needed, and then shrinks up as that space can be reclaimed.

The primary function a stack serves is to store temporary state of functions. When the compiler takes your source code and turns it into machine instructions, one of the things it does is add instructions to manage the stack. When a function is called, it stores any state that it needs to restore on the stack. Exactly how much state this is depends on the function. For example, a function like

```
int add(int x, int y) {
  return x + y;
}
```

doesn't need to store any state. The parameters x and y are passed in r0 and r1, and it returns the result in r0. So all this function needs to do is add r0 and r1, store the result in r0, and return. Since the return address it should go to is store in the link register Ir, all it needs to do is branch back to Ir. If you compile this function with arm-none-eabi-gcc with -Og, the assembly is:

add:

```
add r0, r0, r1
bx lr
```

More complicated functions, though, that allocate a lot of variables, large variables, or arrays, need space for them. This space is on the stack.

Generally speaking, compilers try to put variables in registers. Registers are fast. But recall that of the 16 registers, only r0-r3 are callee-owned. If a function wants to modify r4, it needs to make sure that it restores r4 to what it was before it returns. Therefore, non-trivial functions, when they're called, usually save all of the caller-owned registers they're going to use. E.g., r4.

One register that's very commonly saved is Ir. Recall that the link register stores the address of the instruction the function should branch to when it returns. This is automatically populated with the bl (branch-and-link) instruction. If a function calls any other function, then Ir will be overwritten. It

therefore needs to be saved. If you compile this add10 function

```
int add10(int a) {
  return add(10, a);
}
this is the generated assembly:
```

add10:

```
stmfd
       sp!, {r4, lr}
       r1, r0
mov
mov
        r0, #10
        add
bl
ldmfd
       sp!, {r4, lr}
```

here is equivalent assembly from gcc v. 8.2:

add10:

```
{r4, lr}
push
mov
        r1, r0
        r0, #10
mov
bl
        add
        {r4, pc}
pop
```

Note how strmfd and ldmfd have been replaced by push and pop: these are just useful shorthand and are equivalent. The

```
stmfd
       sp!, {r4, lr}
```


instruction pushes r4 and 14 onto the stack, by storing them at the memory pointed to by sp. The ! after sp means that sp should be automatically decremented by the amount written. So after strmfd executes, sp will have gone down by 8 (since the stack grows down). Similarly, after the ldrmfd instruction the value of sp will go up by 8. The 'fd' means 'full descending stack', so the stack grows down.

Single stack frame int add10(int a, int b) { return a + b; } sp→ caller's frame saved regs

Single stack frame int add10(int a, int b) { return a + b; } sp→ caller's frame caller's frame saved regs locals/scratch

Single stack frame

```
int add10(int a, int b)
{
   return a + b;
}
```



APCS "full frame"

APCS = ARM Procedure Call Standard

Conventions for use of frame pointer + frame layout that allows for reliable stack introspection

gcc CFLAGS to enable: -mapcs-frame

r12 used as fp

Adds a prologue/epilogue to each function that sets up/ tears down the standard frame and manages fp

You'll use this in assignment 4

The stack pointer is always moving -- up, down. For example, suppose you have a snippet of code like this:


```
if (x > y) {
  int array[100];
  // do some processing with array
} else {
  return x + y;
}
```

If the code takes the if branch, it will grow the stack by 400 bytes (100 words), then restore it when the code between the braces {} completes.

This means that, if you stop at any point in the code, it can be very hard to figure out exactly where the current stack frame starts. The compiler carefully generates code that will restore the stack properly, but this means figuring out exactly where the frame starts might require simulating the future instructions. Put another way, optimized code isn't intended to be read and easily understood - it's intended to be executed fast.

This can be tough if you want to run your code in a debugger. It's not hard to figure out what function you're in -- just look at the program counter and see where in the program that instruction is. But if you want to see the entire stack trace, you need to figure out what function called the current one. This requires knowing where the current stack frame starts, and so where the caller's stack frame ends.

To make this easier, ARM has defined a standard way, called ACPS, that a program manipulates stack frames. In addition to the stack pointer, ACPS maintains a "frame pointer." ACPS adds a prologue and epilogue to every function. The prologue sets up a standard format for the start of the stack frame, and stores the frame pointer. The frame pointer points to the beginning of the frame. The prologue always copies the frame pointer and link register to the stack, at a known offset in the stack frame. This means that if you have the frame pointer, you can find both the instruction this function will return to (so the calling function) as well as the frame pointer of the previous stack frame, so where that frame is stored.





This slide lays out precisely how APCS works. The prolog stores the frame pointer, stack pointer, Ir, and program counter. It then sets the frame pointer to the first word of the stack frame.


While the function executes, the frame pointer stays put.


Then, before the function exits, it runs the epilogue. The epilogue returns the frame pointer, stack pointer, and link register. It then branches back to the link register, so the caller function.


You can't pop the pc from the stack because the pc stored on the stack is from the start of the function.














This figure shows how the frame pointers form a linked chain that connects the stack frames.

```
// start.s

// Need to initialize fp = NULL
// to terminate end of chain

mov sp, #0x8000000
mov fp, #0 // fp = NULL
bl main
```

Recall that our start.s sets the stack pointer to the top of memory: 0x8000000. It also sets the frame pointer to 0, to show that there's no stack frame, this is the start of the stack. It's a "null pointer" for the stack.