Data Type – Bit Precision-Assignment: Quiz Solution

www.highlevel-synthesis.com

This file is a resource of the Udemy course: Digital System Design with High-Level Synthesis for FPGA: Combinational Circuits https://www.udemy.com/course/hls-combinational-circuits/?referralCode=8D449A491B9F4582DDEF

Declare a 362-bit width variable of unsigned integer type and initialise that with a value that set all bits to one.

The straitforward way is as shown in the following code

```
ap_uint<362> a = ap_uint< 763 >( "1111111111111111"
                                  "1111111111111111"
                                  "1111111111111111"
                                  "11111111111111111"
                                  "1111111111111111"
                                  "1111111111111111"
                                  "1111111111111111"
                                  "1111111111111111"
                                  "1111111111111111"
                                  "111111111111111"
                                  "111111111111111"
                                  "1111111111111111"
                                  "1111111111111111"
                                  "1111111111111111"
                                  "1111111111111111"
                                  "1111111111111111"
                                  "11111111111111111"
                                  "1111111111111111"
                                  "1111111111111111"
                                  "1111111111111111"
                                  "1111111111111111"
                                  "1111111111111111"
                                  "1111111111", 2);
std::cout << " a = " << a.to_string() << std::endl;</pre>
```

Another way is using the concept of overflow in unsigned operations as shown in the code below

```
ap_uint<362> a = ap_uint< 763 >("0", 16)-1;
std::cout << " a = " << a.to_string() << std::endl;</pre>
```