Basic Output HLS Ports: Quiz Solution

www.highlevel-synthesis.com

We can use the codes in the previous lecture quiz solution and add proper pragmas as shown below

Case 1:

```
unsigned short int basic_output_16LED() {
#pragma HLS INTERFACE ap_ctrl_none port=return
    return 0b0000000011111111;
}
```

Case 2:

```
void basic_output_16LED(unsigned short int *led) {
#pragma HLS INTERFACE ap_ctrl_none port=return
#pragma HLS INTERFACE ap_none port=led

    *led = 0b00000000111111111;
}
```

Case 2:

```
void basic_output_16LED(unsigned short int &led) {
#pragma HLS INTERFACE ap_ctrl_none port=return
#pragma HLS INTERFACE ap_none port=led

led = 0b0000000011111111;
}
```