

Wiring Instructions

Ensure you are facing the front of the sensor (the side with the curved bump/lens) when identifying these pins.

- **Pin 1 (Left Pin):** Connect to the **GND** pin on the Arduino.
- **Pin 2 (Middle Pin):** Connect to the **5V** pin on the Arduino.
- **Pin 3 (Right Pin):** Connect to **Digital Pin 2** on the Arduino.

Libraries to be Installed

You need to install the **IRremote** library (authored by shirriff/ArminJo) to make this code work.

Installation Steps:

1. Open the Arduino IDE.
2. Go to the top menu and click **Sketch**.
3. Hover over **Include Library** and select **Manage Libraries**.
4. In the search bar of the Library Manager, type "**IRremote**".
5. Find the library by *shirriff/ArminJo* in the list and click **Install**.