

## Wiring Connections

The KY-037 Microphone Sound Sensor module has 4 pins. Connect them directly to your Arduino Uno using female-to-male jumper wires:

- **VCC:** Connect to the **5V** pin on the Arduino to power the sensor module.
- **GND:** Connect to any **GND** pin on the Arduino for ground reference.
- **A0 (Analog Output):** Connect to analog pin **A0** on the Arduino. This pin transmits the continuous real-time sound amplitude waveform.
- **D0 (Digital Output):** Connect to digital pin **2** on the Arduino. This pin outputs a **HIGH** signal when the sound level crosses the threshold set by the onboard potentiometer.

## Required Libraries

- **No external libraries are required.** \* The code relies completely on built-in standard Arduino functions (analogRead, digitalRead, and Serial). You do not need to install anything via the Library Manager. Just upload the code directly to your board.