

Hardware Connections

Here is the step-by-step wiring guide for connecting your Arduino, the ISD1820 module, and the speaker:

- **Powering the Module:**
 - Connect the **VCC** pin on the ISD1820 module to the **5V** pin on the Arduino.
 - Connect the **GND** pin on the ISD1820 module to any **GND** pin on the Arduino.
- **Controlling the Playback:**
 - Connect the **PLAYE** pin on the ISD1820 module to **Digital Pin 3** on the Arduino.
- **Connecting the Speaker:**
 - Connect the two wires from your speaker (recommended: 8 Ohm, 0.5W) directly to the **SP+** and **SP-** terminals on the ISD1820 module. Polarity does not matter, so it doesn't matter which wire goes into which terminal.

Required Libraries

- **None!** You do not need to install any external libraries for this project.
- The code relies solely on standard, built-in Arduino core functions (`pinMode()`, `digitalWrite()`, and `delay()`), which are automatically included when you compile any sketch in the Arduino IDE.