

Via S. M. Maddalena, 12 - 38100 Trento - Italy Tel. +39 0461 260552 - Fax +39 0461 260617 email: info@neuricam.com - http://www.neuricam.com

PCCam kit contents

- PCCam smart camera
- 6mm CS-lens
- PS2 Y-cable adapter
- USB cable and adapter
- 64 MB recovery compact flash
- Power supply 12V@800mA
- CDROM containing drivers, manuals and utilities.

Other HW requirements

- Super VGA Monitor 1024x768@85Hz
- Keyboard and mouse connected through the PS2 Y-cable included in the kit.

Mouse/ Keyboard USB Ethernet CompactFlash

Start up the system

- Mount the CS-lens on the camera
- Attach the y-cable to the PS2 connector
- Attach keyboard and mouse to the Y-cable
- Plug the monitor cable to the VGA connector
- Connect the power supply
- Enter the system using login: pccam and password: pccam2003
- Run "startx" to open a X Window session on PCCam.

Live images on the VGA monitor

- Press the right mouse button and open a xterm
- Type "pccam_viewer" and press enter (or "pccam_lpr" for the LPR version)
- Turn off PCCam typing "poweroff" on a xterm.