4. Mounting the clock

HH

The clock needs to be hung flush to a wall so the effect of the LED light bouncing off of the wall is sharp. You can do this by using the small holes in the top of the watchface; loop a thin piece of wire through these holes and tie the ends together. You can now hang the watchface on a screw or nail in the wall without the screw or nail being visible.

Posted - Tue, Jan 15, 2019 10:35 AM.

Article Number: 1159 | Last Updated: Tue, Mar 12, 2019 2:01 PM

Online URL: https://manuals.whadda.com/article.php?id=1159