APEX AND CIRCUIT COILOVERS

Coilover installation guide

Read this guide before you start. You need a lift or jack stands, a torque wrench, a spring preload wrench set and about four to five hours.

Before you begin

Measure and write down the ride height at each wheel arch. Loosen the wheel nuts while the car is on the ground.

1. Raise the vehicle and support it on stands at the manufacturer's lift points. Remove the wheels.
2. Disconnect the sway bar end link and any brake line or sensor brackets from the strut.
3. Remove the lower strut bolts, then the top mount nuts, and lift the strut out.
4. Set the coilover to the starting height in the table on the next page. Lock the collars.

Steps, continued

5. Fit the coilover, torque the top nut to 44 ft·lb and the lower bolts to 85 ft·lb.
6. Refit the brackets, the end link and the wheel. Lower the car and roll it ten feet.
7. Set the damping to the baseline clicks and have the alignment checked.

Torque and settings

Starting height, front	-1.2 in from stock
Starting height, rear	-1.0 in from stock
Baseline damping	12 clicks from full soft
Top nut	44 ft·lb
Lower mount bolt	85 ft·lb
Re-check collars	After 300 miles