TRAIL LIFT AND LEVELING KITS

# Lift kit installation guide

A lift kit changes the geometry of the suspension. An alignment is required afterward, and a re-torque after 500 miles.

## Before you begin

Check the tire size you plan to fit against the maximum on the product page.

1. Raise the front and remove both wheels. Support the lower control arms.
2. Remove the strut top nuts and fit the spacer between the mount and the tower. Torque to 40 ft·lb.
3. Raise the rear and support the axle. Remove the U-bolts.
4. Fit the block between the spring and the axle pad with the pin seated. Fit the new U-bolts and torque to 95 ft·lb in a cross pattern.

## Steps, continued

5. Fit the brake line brackets. Check that lines and sensors have slack at full droop.
6. Refit the wheels, lower the vehicle and have the alignment set.

## Torque and settings

| | |
|---|---|
| Strut spacer nuts | 40 ft·lb |
| U-bolts | 95 ft·lb, cross pattern |
| Re-torque | After 500 miles |