APEX STRUT ASSEMBLIES

Strut assembly installation guide

Assembled struts replace the complete corner. No spring compressor is needed.

Before you begin

Compare the new assembly with the old one before removing anything: mount pattern, length and bracket position.

1. Raise and support the vehicle. Remove the wheel.
2. Disconnect the end link and brackets from the strut.
3. Remove the lower bolts and the top mount nuts. Lift out the old strut.
4. Fit the new assembly, hand tight at the top, then torque the lower bolts to 125 ft·lb.

Steps, continued

5. Torque the top mount nuts to 25 ft·lb and refit the brackets.
6. Refit the wheel, lower the car and have the alignment checked.

Torque and settings

Top mount nuts	25 ft·lb
Knuckle bolts	125 ft·lb
End link	45 ft·lb