# Volta X2 Electric Bike - User Manual

## About the Volta X2

The Volta X2 is a city e-bike made by Northwind Cycles. It has a 250 W rear hub motor, a 540 Wh removable battery and hydraulic disc brakes. The motor assists up to 25 km/h, the legal limit for e-bikes in the European Union.

## Assistance modes

There are four assistance modes: Eco, Tour, Sport and Boost. Press the plus and minus buttons on the handlebar display to change mode. Eco gives the longest range; Boost gives the most support on steep hills.

## Battery and charging

A full charge from empty takes about 4.5 hours with the supplied 4 A charger. Charging from 20 to 80 percent takes about 2 hours. Charge the battery indoors at temperatures between 10 and 30 degrees Celsius. Do not charge it below 0 degrees.

## Range

Typical range is 60 to 120 km depending on the mode, rider weight, terrain and temperature. In cold weather below 5 degrees, expect up to 30 percent less range.

## Storage

For storage longer than one month, keep the battery at 50 to 70 percent charge and check it every 8 weeks.

## Warranty

The frame has a lifetime warranty for the original owner. The motor and battery are covered for 2 years or 800 charge cycles, whichever comes first. The warranty does not cover wear parts such as tyres, brake pads and chains.

## Troubleshooting

If the display shows error E07, the battery is not seated correctly: remove it and click it back into place. Error E12 means the motor is overheating; stop for 15 minutes. For any other error, contact service@northwind.example.

## Servicing

Have the bike serviced every 2,000 km or once a year, whichever comes first.